




**DC
275A**



**DC
200A**

Cyclone 262

*Safety, Setup and General Use Guide For The
Cyclone 262*



FUNCTION: MIG/Stick Welder
PURCHASE DATE:
MODEL NAME:
SERIAL NUMBER:
OPTIONAL ACCESSORY SERIAL NUMBER:

240V 1Ph

Operator's Manual



Welders, Plasma Cutters, Multi-Process

www.everlastwelders.com
Need Parts? Need Technical Help? Call: 1-877-755-9353

380 Swift Ave. Unit 12 South San Francisco, CA 94080, USA

TABLE OF CONTENTS

SPECIAL NOTICE AND CALIFORNIA PROPOSITION 65 WARNING	3
CUSTOMER GREETING AND EXPLANATION OF PROCEDURES	4
WARRANTY AND CONTACT INFORMATION	5
SAFETY DISCLAIMER AND HF WARNING	6
SAFETY WARNINGS, DANGERS, CAUTIONS AND INSTRUCTIONS	7
GENERATOR OPERATION INFORMATION	10
REAR OUTLET INFORMATION	10
SPECIFICATIONS	11
DUTY CYCLE INFORMATION	11
BREAKER AND WIRING REQUIREMENT INFORMATION	12
OPERATING AND ELECTRICAL SPECIFICATIONS	13
GETTING STARTED, UNPACKING YOUR UNIT AND INSPECTION	14
CONNECTING YOUR UNIT TO THE POWER SOURCE AND WIRING INFORMATION	15
SHIELDING GAS, REGULATORS, AND TORCH INSTALLATION AND POLARITY INFORMATION	16
INSTALLING MIG WIRE AND DRIVE ROLL SELECTION, MIG GUN DISASSEMBLY AND SETUP	19
FRONT PANEL VIEW AND COMPONENT ID	21
REAR PANEL VIEW AND COMPONENT ID	22
CONTROL PANEL LAYOUT	23
GETTING READY TO WELD/SETTING UP THE UNIT FOR WELDING MANUALLY	26
SETTING UP THE POWERSSET MODE	29
EXPLANATION OF MIG FUNCTIONS AND TERMS	31
MIG TORCH COMPONENT BREAKDOWN	35
STICK WELDING INFORMATION	36
COMMON MIG/FLUX CORED ISSUES	38
WARNING SCREENS/ERROR INFORMATION	39

NOTICE:

Product Specifications and features are subject to change without notice. While every attempt has been made to provide the most accurate and current information possible at the time of publication, this manual is intended to be a general guide and not intended to be exhaustive in its content regarding safety, welding, or the operation/maintenance of this unit. Due to multiple variables that exist in the welding field and the changing nature of it and of the Everlast product line, Everlast Power Equipment INC. does not guarantee the accuracy, completeness, authority or authenticity of the information contained within this manual or of any information offered during the course of conversation or business by any Everlast employee or subsidiary. The owner of this product assumes all liability for its use and maintenance. Everlast Power Equipment INC. does not warrant this product or this document for fitness for any particular purpose, for performance/accuracy or for suitability of application. Furthermore, Everlast Power Equipment INC. does not accept liability for injury or damages, consequential or incidental, resulting from the use of this product or resulting from the content found in this document or accept claims by a third party of such liability.

WARNING!

California Proposition 65 Warning:

This product, when used for welding or cutting, produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code § 25249.5 et seq.)

 Warning: Cancer and/or Reproductive Harm

www.P65warnings.ca.gov

THANK YOU! We appreciate you as a valued customer and hope that you will enjoy years of use from your welder. We work to please the customer by providing a well supported, quality product. ***To make sure that you receive the best quality ownership experience, please see below for important information and time sensitive details.***

What to do right now:

1. Print your receipt from your confirmation email that should have been sent to you after your purchase and put it up for safe keeping. If you do not have one, contact us at 1-877-755-9353 (US customers) or 1-905-570-1818 (Canadian Customers). You will need this if anything should ever happen for original owner verification (if bought as a gift, original receipt will still be needed, or explanation sent to Everlast).
2. Read this manual! A large number of tech and service calls are a result of not reading the manual from start to finish. Do not just scan or casually peruse this manual. There are different features and functions that you may not be familiar with, or that may operate differently than you expect. Even if you have expertise in the field of welding, you should not assume this unit operates like other brands or models you have used.
3. Carefully unpack and inspect all items immediately. Look for missing or damaged items. Please report any issues within 48 hours (72 hours on weekend or holidays) of receiving your product,. Take pictures if you are able and contact us at 1-877-755-9353, ext. 207 if any issue is discovered between 9 am and 5 pm Eastern Time M-F (US customers) or at 1-905-570-1818 (Canadian Customers) between 9am and 4 pm weekdays except on Fridays when hours are from 9 am to 12pm Eastern. If outside of the US or Canada, contact your in-country/or regional distributor direct at their service number.

What to do within the next 2-3 days:

1. Make sure your electrical system is up to date and capable of handling the inrush and rated current of the unit. Consult and use a licensed and knowledgeable electrician. If you have downloaded this manual in expectation of delivery, get started now.
2. Make sure this machine is plugged in, turned on, and tested with every process and major feature, checking for proper function. You have a 30 day period to test and thoroughly check out the operation of this unit under our 30 day satisfaction period. If something is wrong, this policy covers shipping on the unit (30 day satisfaction policy applies to the USA only for the 48 lower states and D.C., territories and provinces are excluded) or any incidental parts that may be needed to resolve any issue. After this 30 day period, if you find something wrong with the unit, you will not receive the benefit of free shipping back and forth to resolve this issue. Your unit is still covered under the 5 year parts/labor warranty, but shipping is covered by the customer after the 30 day period is over. The first 30 days of operation with any electronic item is the most critical and if any issue will happen, it will often happen during this time. This is why it is very important that you put this unit to work as soon as possible. Any issue should be reported within 48 hours (72 if on the weekend or holiday). Everlast will not be liable for any shipping after that time.

What to do within the next 30 days:

Visit our website (US customers). Go to www.everlastwelders.com. Navigate to the resources tab and to the “product registration” page to register your product. While keeping your receipt/proof of purchase is still required for verification of ownership, registering will help us keep your details straight and establish a chain of ownership. Don't worry, though, your warranty is still valid if you can't do this. Remember: Always keep your receipt even if you register. You may want to staple a copy to your manual.

What to do if you have a warranty issue or problem with the unit:

1. Unplug the unit. (Also do this before any maintenance or cleaning is done.)
2. Do not attempt a self-repair until authorized by an Everlast representative. This does not include performing routine maintenance such as point gap adjustments or regular internal cleaning. Any third party repairs are not covered under warranty, and can further damage your unit.
3. Within 24-48hours, (or by the next working business day) you must contact U.S. tech support at 1-877-755-9353 ext 207 (U.S. hours are 9 am to 5pm Eastern for tech support and 9 am to 5 pm Pacific for the business/sales office). If you are in Canada contact 1-905-570-1818 (Canada hours are 9am to 4pm M-Th, 9am to 12pm Fri). Although phone contact is preferred to establish a warranty claim, you may send an email to tech@everlastwelders.com (US) or mike@everlastwelders.ca (Canada) along with your contact information and brief explanation of the issue and ask for a follow up call. If you contact us via phone, and you do not reach a live person, please leave a brief message with the nature of your problem and your contact information. You should expect a call back within 24 hours. It is also a good idea to follow up the message with an email.
4. Be prepared with as much information as possible when you talk with a tech advisor, including a details of the failure, settings, and application of the unit. ***NOTE: A Proof-Of-Purchase (receipt) is required before returning the unit for warranty or before warranty parts can be sent to you.***
5. Keep in mind that, you may be asked to check a few basic things. Before you call, having a screwdriver and volt/ohm meter at hand is a good idea and will save time. Many issues can be resolved over the phone. If the issue cannot be resolved over the phone/email, you may be given an option to return the unit, or have a part shipped to you, at Everlast's discretion. Keep in mind, you may be asked questions that seem basic, or elementary to your knowledge base. These are not meant to question your knowledge, but rather to make sure nothing is overlooked. However the tech chooses to proceed, please cooperate with the process, even if you think you know what the cause or issue is. You may be asked to check something or open the unit during the diagnosis. This does not void the warranty! Opening the unit is a part of routine maintenance and cleaning. This is an important step. The willingness of the customer to work with tech support can save lots of time and accelerate the warranty process. For

warranty to be honored, you will need to make sure that you follow these guidelines. *Units that are returned without an RMA (issued by the tech support department) may not be repaired under the warranty agreement and you may be charged for the repair and can result in a delayed repair as well.*

What to do if you need setup help, guidance, weld issue diagnosis or have general product compatibility questions.

Call us at 877-755-9353 ext. 204 for welding guidance and general welding issue diagnosis. Or email performance@everlastwelders.com with the basic issue you are having, along with your specific settings, and welding application.

Hey...wait, what is my warranty?

Warranties and service policies and procedures vary from country to country and are maintained and supported by the regional or in country distributor of Everlast welding equipment.

USA Customers Only: For full details on the 5 year parts and labor warranty, 30 day satisfaction policy, terms of sale, and how to proceed with a warranty claim, please visit: <https://www.everlastgenerators.com/standard-warranty>. Accessories are covered by a separate warranty and detailed information can also be found at the link above.

Canada Customers Only: For full details on the 3 year parts and labor warranty, terms of sale, and related policies and procedures, please visit: <https://www.everlastwelders.ca/terms.php>.

Who do I contact?

USA Technical Support:

Email: tech@everlastwelders.com
1-877-755-9353 ext. 207
9am-5pm Eastern (Closed holidays)
Monday-Friday

USA Welding Support and General Product Information:

Email: performance@everlastwelders.com
1-877-755-9353 ext 204
9am-6:30 pm Eastern (Closed holidays)
Monday-Friday

USA Sales and Main Office:

Email: sales@everlastwelders.com
1-877-755-9353 ext 201
9am-5pm Pacific (Closed holidays)
Monday-Friday

Canada Technical Support:

Email: mike@everlastwelders.ca
905-570-1818
9am-4pm Eastern Monday-Thursday
9am-12pm Eastern Friday

Canada Sales and Main Office:

Email: sales@everlastwelders.ca
905-570-1818
9am-4pm Eastern Monday-Thursday
9am-12pm Eastern Friday

Other Countries and Regions:

Visit the U.S. Website @ www.everlastwelders.com and click on the flag of the country or region represented that is closest to you. If your country or region is not found, call the U.S. office at 1-650-588-8588 between the hours of 9am to 5pm Pacific, Monday through Friday.



Safe operation and proper maintenance is your responsibility.

Everlast is dedicated to keeping safety a top priority. While we have compiled this operator's manual to instruct you in basic safe operation and maintenance of your Everlast product, it is no substitute for observing safe welding practices and behavior. Safe welding and related cutting operations require basic knowledge, experience and ultimately the exercise of common sense. **Welding does significant hazards to your health and life! Exercise extreme caution and care in all activities related to welding or cutting. Your safety, health and even life depends upon it.**

WARNING! If you do not have proper knowledge or capability to safely operate this machine, do not use this machine until proper training has been received!

While accidents are never planned, preventing an accident requires careful planning. Stay alert!

Please carefully read this manual before you operate your Everlast unit.

The warranty does not cover damage or harm created by improper use, neglect of the machine or failure to follow safe operating practices.

NOTICE:



Welding and cutting operations may generate undesirable High Frequency (HF) and EMF energy. This can interfere with surrounding electronic equipment such as computers, routers, CNC equipment, televisions, radios, fluorescent lighting etc. If disturbance in surrounding electrical and electronic equipment is noted, consult a licensed electrician to help properly ground surrounding equipment to limit the interference. This machine may cause GCFI and ground fault outlets to malfunction. This unit is designed to be operated on a dedicated, properly grounded circuit.

Safety Warnings, Dangers, Cautions and Instructions



NOTICE. This unit manual is intended for users with basic knowledge and skillset in welding. It is your responsibility to make certain that the use of this welder is restricted to persons who have read, understand and follow the warnings and instructions in this manual. If you or the operator needs further instruction, contact Everlast welding support at 1-877 755-9353 ext. 204 or seek qualified professional advice and training.



WARNING! High Frequency (HF) energy can interfere with the operation of pacemakers and can damage pacemakers. Consult with your physician and pacemaker manufacturer *before* entering an area where welding and cutting equipment is in operation and *before* using this welder. Some pacemakers have limited shielding. Alert any users or customers of this potential problem.



WARNING! Use approved safety glasses with wrap around shields and sides while welding and working in the weld area or serious eye damage or loss of vision may result. Use a grinding shield in addition to the safety glasses during chipping and grinding operations.



WARNING! When welding always use an approved welding helmet or shielding device equipped with at least an equivalent of a shade 9 or greater. Increase the shade number rating as amperage increase over 100 amps. Inspect helmet for cracks in lenses and in the helmet. Keep lens covers in good condition and replace as necessary.




WARNING! Welding/cutting operations carry inherent risks which include but not limited to possible cuts burns, electrical shocks, lung damage, eye damage and even death. Take all appropriate measures to use proper Personal Protective Equipment (PPE). Always use leather welding gloves, closed toe (preferably reinforced or steel toe leather shoes, and long-sleeved flame resistant clothing (i.e. denim). Do not wear Poly/Nylon blend materials.



DANGER! Welding/cutting poses shock and electrocution risks. Keep this welding equipment dry. **Do not weld in the rain or where moisture accumulates.** Use dry, rubber soled shoes, gloves and clothing when welding. Do not rest or contact work clamp (ground) when welding. Keep all parts of the body insulated from the part being welded when possible. Do not touch terminals or connections while the unit is on. Consider all parts to be "live" at all times even if no live work is being performed. Do not use frayed welding cables.



CAUTION! Fires are possible but also preventable while welding. Always remove flammable rags, papers, and other materials from the weld area. Keep rags stored in an approved flame proof canister. Keep a fully charged fire extinguisher at hand. Remove any fuels, oils, paint, pressurized spray cans, and chemicals from the weld area. Make sure any smoke/fire detectors are function properly. Do not weld on tanks, drums or barrels, especially if pressurized or sealed. Do not weld on any container that previously held fuel or chemicals. Make sure the weld area is clear of flammable materials such as grass or wood shavings solvents and fuels. Do not wear frayed or loose clothing. Visually inspect and recheck the work area after welding looking for smoldering debris or flames.



WARNING! Welding gas cylinders are under high pressure. Keep all gas cylinders upright and chained to a cart or held safely in a safety holding pen. Never transport gas cylinders in an enclosed car van or other vehicle. Transport gas cylinders securely. Keep all cylinders capped while not in use or during transport. Replace the cap on the cylinder when it is going to be more than 24 hours before use. Do not use or attempt to repair faulty regulators. Never weld on gas cylinders. Keep gas cylinders away from direct sparks.

Safety Warnings, Dangers, Cautions and Instructions



DANGER! Welding and cutting operations pose serious inhalation hazards. Some of these hazards are immediate while others are cumulative in their effect. **Do not weld in enclosed spaces or in areas without adequate ventilation.** Fumes and gases released in the welding and cutting operations can be toxic. Use fans or respiration equipment to insure adequate ventilation if you are welding in a shop or garage area. **Do not weld on galvanized metal under any circumstance.** You may develop metal fume fever. Symptoms are similar to flu-like symptoms. Seek medical advice and treatment if you are exposed to galvanized welding fumes.

If you experience any eye burning, nose or throat irritation while welding, these are signs that you need more ventilation.

If you feel these symptoms:

- Stop work immediately and relocate work area with better ventilation.
- Wash and clean your face and hands.
- Stop work completely and seek medical help if irritation persists



DANGER! Never use brake cleaner or any chlorinated solvent to clean or degrease metal scheduled to be welded or other related equipment in the area being welded. The heating of this cleaner and its residue will create highly toxic phosgene gas. Small amounts of this vapor are harmful and can lead to organ failure and death. If degreasing of a part is necessary, use Acetone or an approved pre-weld cleaner. Use the proper personal protective equipment (PPE) when handling any cleaners/solvents.



DANGER! People with pacemakers should consult a physician and pacemaker manufacturer before welding. There is a potential for damage or serious malfunction resulting in death. High Frequency energy (HF)/Electromagnetic Fields generated during welding can interfere with pacemaker signals, even permanently damaging it. Some pacemakers offer some shielding, but restrictions regarding amperage and HF starting of welding arcs may be placed upon the individual. Warn all potential bystanders that they should exit the work area if they have a pacemaker or similar medical equipment before welding. In adverse conditions, severe electrical shock leading to injury or death may occur while using the welder if the user becomes part of the circuit path. Consult with a Physician if a pacemaker is expected to be implanted.



DANGER! Never defeat or modify any safety guards or shields. Keep all safety covers and shields in place.

Never place your fingers in or near a fan shroud or insert any object into the fan(s).



DANGER! Do not weld on the gas cylinder. Do not weld near fuel, cleaners, solvents or other flammable materials. Remove these items from the premises before welding. Severe injury or death may result from explosions or fires may occur.

Safety Warnings, Dangers, Cautions and Instructions

	CAUTION! Trip Hazards exist around this unit. Cords, cables, welding leads and hoses pose a trip hazard. Be aware of their location and inform others of their location. Tape and secure them so they will stay out of high traffic areas.
	CAUTION! Welded metal can stay hot long after welding is completed. Burns may occur. Always wear gloves or use tongs/pliers when handling welded or cut metal. Remember the heat from the metal may catch other material on fire. Always have a fire-proof area ready to place welded components until they fully cool. Use soap stone or a metal marking marker to label the metal as “HOT” to serve as a reminder to all present in the area.
	CAUTION! Welding and cutting operations generate high levels of ultraviolet (UV) radiation which can burn and damage skin and eyes. The intensity is so high that exposed skin and eyes can burn in a few minutes of exposure. Minimize direct skin and eye exposure to this intense form of radiation by using proper PPE and sun screen where appropriate.
	CAUTION! Do not allow bystanders. Do not allow others without proper Personal Protection Equipment (PPE) suitable for welding to stand in the welding area or to observe welding and welding related activities. If protection is not readily available, use a welding screen to separate the welding area from the rest of the area. If no protection or screen is available, physically exclude them from the welding area by a wall or other solid divider. Keep all pets and young children away from the welding area.
	CAUTION! Electromagnetic Fields can be generated by this unit and radiate into the work place. The effect of EMF is not fully known. Exercise caution when welding by: NOT draping welding leads (guns/cables) over your shoulders or arms, NOT coiling them around your body, NOT inserting yourself directly between the cables, and by NOT contacting the unit while welding. DO keep the work clamp connected as close as possible to the area of the weld and directly to the object being welded whenever possible.

Important Information: Operating this unit with a generator or other off-grid service.

MINIMUM REQUIRED SURGE WATT RATING: 12,500W

MINIMUM REQUIRED THD: 5% or Less

This welder unit should only be operated on a generator certified by its manufacturer to produce clean power. Clean power is equivalent to the quality of household or shop/garage type power. This means the generator must have 5% or less total harmonic distortion (THD) of the Sine wave. If you are unsure of the power output type of the generator, contact the manufacturer of the generator for verification. *Do not operate on square wave or modified square wave generators or converters/inverters or damage or malfunction may occur. Damage caused by running this unit off of "dirty" power or modified sine waves may not be readily apparent and can be cumulative in nature. However, damage may present itself immediately. The damage caused by running this unit on "dirty" power usually leaves internal tell-tale signs and damages specific parts.*

NOTICE! Operation of this unit with generators not rated by its manufacturer as providing clean power (5% or less THD) is prohibited and will void the warranty. Operation with modified sine wave, or square wave generators and inverters/converters/UPS that do not produce "sine wave" output is prohibited and doing so will also void the warranty. Use only with generators/inverters/converters that produce an equivalent type of sine wave used in shops, homes and "shore" type systems. *The generator manufacturer determines the THD rating, not Everlast.* Do not assume that a name brand generator, or a "new" generator automatically provides clean power. Price paid does not guarantee a clean power output either. There are multiple brands at various price points capable of producing clean power. Investigate this before purchasing a generator. The manufacturer will usually state that a unit is clean power in the advertising information and will state actual THD. If the manufacturer does not state it, contact the manufacturer directly for a statement concerning actual THD.

WARNING! Do not start or stop the generator with the unit switched on. Never use the generator in ECO mode or an auto-idle mode. Even with a clean power rated generator, this action can damage the unit. *Turn the unit on only after full generator R.P.M. has been achieved and the engine is sufficiently warmed up.* Closely monitor generator fuel level so that the engine R.P.M doesn't drop or completely shut down with the unit plugged in. **For best practice: do not start or stop the generator with this unit plugged in, even if it is turned off. Unplug the unit before shutting down the generator.**

If using with a welder/generator, make sure the manufacturer has determined that the generator portion produces a clean sine wave. Many older models do not. Some newer models use "divided" power between welding and generating and cannot supply the full power to the unit unless the fine current control knob is turned to maximum. Do not use this unit with such welder/generators unless the Power/fine current control is turned to 100%. Some welder generators do have a separate alternator for generating power. If this is the case, be sure not to weld or load the machine while this unit is in use.

WARNING! Always make sure any generator or welder generator is properly wired and grounded, according to local and national code. Ground the machine per the generator manufacturers instructions to meet code requirements. Improperly grounded generators may damage the machine and more importantly may cause severe injury or death.

240V Operation:

This unit is designed for 240V ($\pm 10\%$) 50/60Hz single phase operation. This is the standard single phase, Voltage in the North American market used for most welders. If your voltage is derived from 208V 3 phase Wye Type power (or your local power company provides measured voltage 216V or less across each hot leg of power), then it is recommended that you install a buck-boost type transformer. If you are not sure which voltage you have, contact your local electrician and/or power company. Operation on 208V will affect accuracy of adjustment and output. If the voltage drops below 205V under load or during peak periods, damage may occur to the unit. Damage caused by using on undervoltage power sources or inaccuracy in operation is not covered by the warranty. Always be aware of the voltage output and the quality of the power source being used.

Rear Outlet Use and Warning:

WARNING: If equipped, never use the electrical power outlet on the back of this machine for anything other than powering an Everlast brand water cooler. This is a special outlet designed to produce 240V with limited amperage draw. No other device or brand should be used in conjunction with this unit's outlet. This outlet is designed to supply 240V only. Do not attempt to modify, or change this outlet for use with anything else other than an Everlast brand water cooler designed for 240V operation. Severe damage, fire or injury may occur if other devices or other brand equipment is connected.

Specifications

Duty Cycle

Duty Cycle is simply the amount of time out of a 10 minute period in which the unit can operate. For example, this unit has a duty cycle of 50% at maximum output (MIG or Stick). This means the unit can be operated for 5 minutes out of 10 minutes. The unit may be operated continuously, or intermittently for 5 minutes during the 10 minute period of time while the machine is MIG welding at maximum output. This rating standard (United States) is based on a maximum ambient temperature of 40°C (104°F). Operating at or above this point, or even at slightly lower temperatures with high humidity may reduce the duty cycle rating. Of course, the duty cycle will increase somewhat as ambient temperature drops. Lowering the operating Amperage to just 250A will see a significant rise in duty cycle up to 60%. From there duty cycle continues to rise so that MIG welding at 195A will increase the duty cycle to 100%. Duty cycle is important to determining what type of work welder is suitable for. However at 50% duty cycle while welding at maximum output, it is rare that manual welding will exceed the duty cycle of the machine, since there is a lot of “in between” work such as grinding, repositioning, cleaning etc. that is often needed between welds.

Even though the machine has a 100% duty cycle rating level of 195A on this machine, this does not mean that the welder will operate continuously at this level beyond the 10 minute mark. This is not an infinite rating. Don't forget that the 100% rating is a rating based off a defined 10 minute period of time. Depending upon the circumstances, the welder could go into overheat mode at the 11 or 12 minute mark even though it is rated for 100% at 10 minutes.

Regardless of the duty cycle rating, this unit's duty cycle is not controlled by a timer. Rather, this unit is equipped with a heat sensor located on a heat sink near the critical power components of the welder. If the operating temperature of the unit is exceeded, welding output will stop and an over-temperature warning light/error code will be displayed on the panel. **If a duty cycle event is registered, do not turn the unit off!** Allow the welder to continue to run at idle for at least 10-15 minutes until the temperature has fallen enough to reset the sensor and over-temperature warning light. *Even if the unit resets, allow the unit to cool for a full 15 minutes, or the duty cycle will be more quickly triggered since the unit resets just below the heat threshold. The fan(s) must continue to run for a full 15 minutes to cool the unit properly after the duty cycle shut down has occurred.* After 15 minutes of cooling, you may switch the unit off if you are finished welding. If the unit does not automatically reset after 15 minutes, turn the unit off. Wait for 15 seconds before turning the machine back on. If the unit does not reset, contact technical support for further advice and assistance. As a best practice, when you have completed welding and have been welding continuously for extended periods of time, keep your unit on for 10 additional minutes without welding to allow it to cool.

Keeping the unit clean will help maintain the duty cycle of the welder. Removing the cover and blowing it out with dry compressed air, every 3 to 6 months will help maintain air flow and cooling surfaces and will allow the unit to operate at maximum efficiency.

The intentional and/or repeated triggering of the duty cycle protection feature on this unit will shorten the lifespan of the unit's electronics and can weaken internal components. The effect of overheating your unit repeatedly takes a cumulative toll on the unit.

NOTICE: These units are tested by an international and independent certifying agency for their ability to sustain the claims of duty cycle, under lab induced conditions which are typically more stringent than average shop conditions.

Specifications

BREAKER SIZING AND WIRING REQUIREMENTS

Before installation of this unit in any facility, always consult a licensed local electrician familiar with the requirements of properly wiring a welder into the electrical supply. Refer to the National Electric Code (NEC) and local codes. If needed, refer the electrician to Article 630 of the NEC during consultation to determine proper application and wiring needs. Use the I1MAX and the I1EFF ratings listed above to determine the proper breaker and conductor (wire) sizing required. Everlast welders are designed around use in industrial wiring applications and are intended to be used with modern electrical systems. Household wiring may need to be upgraded before this welder may be installed. Additional HF protection and isolation may be needed if this welder interferes with the operation of electrical/electronic equipment. This unit should be operated only on a dedicated branch circuit.

IMPORTANT: Do not modify this unit's wiring, power plug or conductors. This unit meets the standards for conductor sizing on the power cable and takes into account power cable length, duty cycle and rated current.

NOTICE: POSSIBLE HF INTERFERENCE FROM THE INVERTER AND WHAT TO DO IF IT OCCURS

If any electrical disturbance is noticed as a result of the high frequency interference that is possible with the operation of the inverter switching and operation, the HF service bolt should be connected directly to a 12 gauge wire that is bonded directly to an outside copper ground rod driven into moist soil. Additionally, all metal items including any metal frame or sheeting of the building should be connected and grounded to separate copper ground rods driven into the ground at 10 foot intervals around the perimeter of the building. This includes items such as tables, carts, rack material, metal surrounds, etc. that may act as "antenna" to radiate/absorb HF energy. Additionally, all cords and welding leads should be twisted together and run directly to the work without coils or excess cabling. Normally, this will not be required, but it is supplied in the case of any interference that may be observed. This is usually observed in older or non standard installations where grounding and ground isolation is a problem. Normally this is not needed, but if interference is observed, first try relocating the welder and affected objects, and re-route welding cables. If operation is not improved, contact an electrician to wire the ground and make proper ground connections to all metal objects.

WARNING!

This unit is not designed for Air Carbon Arc Gouging/Cutting or scarfing operations. Do not use this unit for these applications. It is not designed to sustain the high volt and long arc characteristics needed for Carbon Arc cutting/gouging use.

Specifications

Cyclone 262 Product Specifications

Construction Type	Inverter (IGBT based, Digital Control)
Input Voltage	240 V (± 10%) 50/60 Hz Auto-Adjusting
Phase	1 Phase 50/60Hz
I1MAX Current Rating (Inrush Amps)	48.2A
I1EFF Current Rating (Rated Amps)	35A
OCV	70V
MIG Duty Cycle @ Rated Outputs (Rated at 40° C/104° F)	50% @ 275A, 60% @ 250A, 100% @ 195A
Stick Duty Cycle @ Rated Outputs (Rated at 40° C/104° F)	50% @ 200A, 60% @180A, 100% @ 140A
MIG Output Range V/A (DC Output Only)	15.5-28V/ 30-275A
Stick Output Range V/A (DC Output Only)	20.4-26.4V/10-200A
Stick Voltage Reduction Device (VRD)	Yes
MIG Wire Feed Speed:	60-600 IPM
MIG Up and Down Slope Time	0-1 Seconds
MIG Inductance	1-100%
MIG Burn Back Time	0-2 Seconds
MIG Spot Time	.5-15 Seconds
MIG Stitch Time	0-15 Seconds
MIG Run In Feature (Slow Wire Feed Start for improved starting)	On/Off
MIG Wire Size Handling Capability	.023"-.062" (.023" and .030" will require optional liner/gun purchase.)
MIG Spool Size	4" or 8"
MIG Drive Roll Sizes Included	.023"/.030", .035"/.045", .045"-.062" V-Groove for MIG (.6mm/.8mm, .9mm/1.2mm, 1.2mm/1.6mm)
Pre Flow Time	Auto, 0-10S
Post Flow Time	Auto, 0-10S
Stick Hot Start Time	0-2 Seconds
Stick Hot Start Intensity	0-100% above set Amperage)
Stick Arc Force	0-100% above set Amperage
Stick 6010 Capable	Yes
MIG Gun Type/Length/ Connector Type	Innotec MB36KD Series 10ft/ 3m w/ Euro Quick Connect
250A Work Clamp with Cable Length	6.5 ft (2m) DINSE 35/50 (1/2 nom. dia.)
250A Stick Electrode Holder Length	9.5 ft (3m) DINSE 35/50 (1/2" nom. dia.)
Power Cable Length	6.5 ft (2m)
Power Plug Type for Single Phase Operation 240V	NEMA 6-50P (Standard 240V Welder Type)
Cooling Type	Full Time, High Volume Fan(s)
Dimensions (Approximate)	18" H X 11.25" W X 26" L (457mm X 286mm X 661mm)
Weight (Bare Unit with Cord and Handles Attached)	68 lbs.
Ingress Protection Rating	IP21S

*Duty Cycle

Duty Cycle is simply the amount of time out of a 10 minute period in which the unit can operate. For example, this unit has a duty cycle of 50% at maximum output, that means that the unit can be operated for 5 minutes out of 10 minutes. This is rated for continuous or intermittent use during the 10 minute period of time. This rating standard (United States) is based on a maximum ambient temperature of 40°C. Operating above this point, or at lower temperatures with high humidity may reduce the duty cycle rating. Of course, the duty cycle will increase somewhat as ambient temperature and output Amps drops as well. Regardless, the duty cycle is not controlled by a timer. Rather, a heat sensor located on a heat sink near the critical power components of the welder signals overheat. If the operating temperature of the unit is exceeded, welding output will stop and an over-temperature warning light/error code will be displayed on the screen. **If a duty cycle event occurs, do not turn the unit off!** Allow the welder to continue to run at idle for at least 10-15 minutes until the temperature has fallen enough to reset the sensor and over-temperature warning light. *Even if the unit resets, allow the unit to cool for a full 15 minutes, or the duty cycle will be more quickly triggered since the unit resets just below the heat threshold. The fan(s) should be allowed to continue to cool for a full 15 minutes without welding/cutting activity after a duty cycle shut down has occurred.* After 15 minutes of cooling, you may switch the unit off if you are finished welding. If the unit does not automatically reset after 15 minutes, turn the unit off. Wait for 15 seconds before turning the machine back on. If the unit does not reset, contact technical support for further advice and assistance. As a best practice, before shut down, if you have been welding continuously for extended periods of time, keep your unit on for 10 additional minutes to allow it to cool down. **The intentional and/or repeated triggering of the duty cycle protection feature on this unit will shorten the lifespan of the unit's electronics and can weaken internal components. Overheating your unit repeatedly takes a cumulative toll on the unit.**

Breaker Sizing and Wiring Requirements

Before installation of this unit in any facility, always consult a licensed local electrician familiar with the requirements of properly wiring a welder into the electrical supply. Refer to the National Electric Code (NEC) and local codes. If needed, refer the electrician to Article 630 of the NEC during consultation to determine proper application and wiring needs. Use the I1MAX and the I1EFF ratings listed above to determine the proper breaker and conductor (wire) sizing required. Everlast welders are designed around use in industrial wiring applications and are intended to be used with modern electrical systems. Household wiring may need to be upgraded before this welder may be installed. Additional HF protection and isolation may be needed if this welder interferes with the operation of electrical/electronic equipment. **WARNING!** Do not modify welder wiring. This unit meets the standards for conductor sizing on the power cable and takes into account power cable length, duty cycle and rated current.

Setup Guide

Getting Started

UNPACK YOUR UNIT.

Upon arrival, you will need to completely unpack your unit, and check things over. This is a time sensitive matter. Do not delay or hold the welder unopened in the box. First, make sure the unit is opened from the top. Be careful with using knives and sharp objects so you won't cut cords and cables inside the boxes. Lay all items out and inspect them.

You should have the following in your box:

1. Cyclone 262 MIG/Stick welder (bare unit).
2. Floating Ball Regulator for MIG. (hose included but not pictured).
3. 36 Series MIG Gun/Torch. (MB36KD style).
4. 250A Work Clamp (approx. 9.5 ft with cable).
5. 250A Stick Electrode Holder (approx. 9.5 ft with cable).
6. Drive Roll Assortment Kit.



NOTICE:

This unit includes an additional MIG contact tip, but does not contain any other MIG consumables, including filler (MIG or Flux-Cored) wire. Additional sizes of contact tips, nozzles and basic gun parts are available direct from Everlast's website, from other online sources and from select local welding supply stores that carry parts for similar MB36KD styled MIG guns. Some miscellaneous parts like a contact tip wrench may be found in the box, depending upon your region. Filler (MIG and Flux-Cored) wire should be purchased locally or direct from other online sources. **Other drive roll sizes and types should be purchased direct from Everlast.** The included drive roll is a V groove drive roll, designed for solid steel wire. Depending upon region drive rolls flux core or aluminum use, must be purchased separately. Flux-Cored wire will have a serrated or zippered appearance in the groove. Aluminum drive rolls will have a U-groove shape. Any 4 roll drive rolls (2 pc kits) offered by Everlast will fit this unit. See more drive roll information found later in this manual for identification of sizes and types.

NOTE: If you think you are missing a needed part, check the consumable kit bag and box before calling Everlast for replacement. If you are missing parts, call 1-877-755-9353 ext. 206 for help. (USA only. For other regions contact the distributor in your country.)

INSPECT AND ASSEMBLE YOUR UNIT.

When you receive your package, inspect the unit for damage. Check for the presence and general condition of the accessories. Some slight rubbing or chaffing of some of the accessories may be present, but this is considered normal. Most notably, the MIG torch may appear to be used or fired. This is because it has been live tested in the factory for proper operation before putting into the box. If any item is damaged or missing, please inform Everlast within 72 hours of product receipt. See pages 4 and 5 for more details.

Assemble the handle with the supplied screws. Use a 5mm hex key to tighten the socket head cap screws to the center mounted handle. (Screws may be found in the consumable bag.) If present, remove the cap screws from the center of the machine and install the center handle and install the handle. If screws are not pre-installed in the welder, check the consumable bag or clam shell box for them.

IMPORTANT! Do not overtighten the screws. *If desired for proper fitment or for space saving, the unit may be used without the handles. However, install the screws and tighten them to the panels anyway. Do not leave them out. Be sure to reinstall the handles if the unit is to be carried or lifted. Do not lift from any other point on the machine or damage may occur.*

POWER UP AND TEST YOUR UNIT.

You will need to fully test the unit as soon as possible. Within 72 hours after receipt of the unit, be sure to have every thing you need at hand to test the unit. Make sure the correct input power, wiring, and plug configuration is being used. Make sure you have the regulator is installed (See following section). Then, power up your machine without any accessories installed. Allow the unit to idle for 15 minutes. Check and observe operation of knobs, controls and buttons, cycling through each as required. Make sure the fan is running at full speed. After the static running test is completed, turn the unit off, connect the torches and cables. Then, conduct live testing of all the functions and features of the machine. For testing make sure work clamp is connected directly to the part being welded (work). Check for arc starting and stability. If any welding problems are observed and they persist, contact Everlast. Make sure however, before you contact Everlast that polarity is correct for the process being used. Improper polarity will result in poor welding performance and in some cases, can result in no arc at all. See page 5 for more contact information. **NOTICE:** *Cosmetic damage claims after 30 days will not be accepted, unless Everlast is contacted and informed of such delay and reason for such a required delay (i.e. Overseas, or while on deployment with the armed services etc.).*

GIVE YOUR UNIT SOME SPACE TO COOL.

This unit needs room to cool itself and maintain proper duty cycle. Place the unit in a place that will allow 18" from all sides to allow for proper cooling. This welder pulls air in from the rear, and pushes it through the unit's heat sinks to cool the electronics. The air is then exhausted through the front panel and side louvers of the unit. If any of sides is blocked or restricted, the duty cycle will be reduced, and overheating will occur, leading to possible damage if the restriction is severe enough. Never attempt to restrict air flow by attaching filters to the vents or by modifying your fans for "on demand" service. If the sound from the welder fans diminish or become non existent, check fans for proper operation. If, over time, you suspect one or more of the fans are not working, discontinue use until the unit can be repaired to prevent

Setup Guide


Getting Started

damage to the machine. One fan not working will cause duty cycle to drop drastically. If your duty cycle warning appears unexpectedly, and continues to do so, contact Everlast tech support for help on checking fan operation and diagnosing the cause.

CONNECT YOUR UNIT TO POWER.

Your unit has been shipped with a NEMA 6-50P plug. This is the standard plug used for 240V 1 Phase welders in North America. For single phase 240V connection, select a NEMA 6-50 Receptacle for operation with this unit. (Other regions/countries vary). A neutral is not used. In a dedicated circuit, the wire wires supplying power (the conductors and ground) are black, white and green. A red wire, which is traditionally used as a "hot" leg (power conducting wire) of power is not present in a three-wire 240V wire circuit of a welder. For welders, from the panel box, the black wire serves as L1(Hot), white serves as L2 (Hot) and green serves as G (Ground). A red wire will not be used as a conductor in a single phase 240V welder circuit. No neutral wire is needed, so white is used as a "hot" conductor wire in this instance. It is recommended to either install a receptacle as close to the main panel as possible or install a subpanel cutoff as close to the outlet and welder as possible. Always follow local codes when making these connections. **This unit should be used on a dedicated circuit and should not share operation of another device on the same breaker.**

Standard Plug Configuration 1 Phase 240V



NOTICE:

There are special rules centered around wiring service for a welding machine. The National Electric Code under Article 630 has developed specific set of electrical service regulations wiring for welding equipment. These are different than for other types of service such as a stove or dryer in a household or even in a commercial application. You need to consult and/or employ a locally licensed electrician before installing this unit to make sure all national and local codes are followed. Do not wire connections for this machine if you are not qualified. Everlast is in no way liable for any damages caused by improper connection of this unit. Your welder should be operated on a dedicated branch circuit not far from an electrical disconnect box. Importantly, it should not share circuits with other shop or household items. Do not attempt to "adapt" existing circuits because conductor (wire) colors are different for welders with 3 wire configuration than for an appliance with 4 wire operation. (Unless adapting with an approved adapter when being powered with a "clean power" generator.) No neutral is used in a welder circuit. The white wire is a conductor in a single phase welder service. It is not used as a neutral. ***The input power cable conforms to North American standards for size, length, with consideration given to inrush amperage, rated amperage and duty cycle. Do not attempt to modify or rewire your unit.***

NOTICE:

The unit is designed with several features and functions in common between processes. The principles of setup and operation carry over from one process to another. In this case, information may not be repeated in detail in this manual if it has been discussed previously in

Selecting A Breaker and Wire Size

Select a breaker based off of the I1MAX rating of this unit. This is the maximum inrush current of the unit. The inrush is not a sustained current. The I1EFF rating of the unit is the maximum "rated" current of the machine. When combined with the length of the run from the main panel, this determines the conductor size. Refer your licensed, local electrician to Article 630 of the NEC and the specification page of this manual (or the specification grid printed on your unit) to select the correct breaker and wire size. A delayed trip breaker, or slow blow fuse should be used with this unit.

Setup Guide

Getting Started

CONNECT YOUR UNIT TO THE CORRECT SHIELDING GAS.

What Shielding Gas Should Be Used?

The Cyclone 262 is a synergic unit which incorporates the type of gas and metal wire being welded with as a base to make accurate "PowerSet" settings. It is important to pay attention to the type of gas used while in "PowerSet" mode or the unit may not determine an accurate setting. The following gases should be used and are the best choices in the gas selection during initial setup after powering the unit up:

Steel: 75%/25% Ar/CO₂ (75/25 or C25) **OR** 100% CO₂ (C100)

Stainless (Inox): 98%/2% Ar/CO₂ (98/2)

Aluminum: 100% Ar (Argon)

Notice that Steel has a couple of gas choices. ***In the North American Market, 75/25 is the standard gas choice for short circuit MIG.*** It provides less spatter than CO₂ and a cleaner, less oxidized weld in general. 100% CO₂ is cheaper, but can require more cleanup and descaling after the weld is completed. In other markets, 100% CO₂ is more commonly available, or may offer slightly different combinations. If 75/25 gas mix is not available for use with the PowerSet setting, and 80/20 is an option, then this gas may be used on the 75/25 setting, but may require slight tuning to achieve perfect performance.

Stainless gas mixes can range throughout the industry. However, in the industry, this unit is designed to be used with 98/2 Ar/CO₂ blend when welding Stainless Steel. While there are other gas choices, such as "TriMix" this is typically the most widely available and economic one for welding Stainless Steel (Inox).

Aluminum will always require the use of pure Argon (100% Ar) shielding gas while welding in MIG mode. This is a widely available and a standard gas throughout the world.

Of course, if you choose manual mode, different gas mixes other than what is suggested may be used. If you choose to use a different gas, be sure to select the next closest gas featured on the panel during setup that matches your selection and keep "PowerSet" turned off. This will allow proper operation.

Always wear safety glasses when changing a cylinder. Before installing any cylinder, stand to the side of the valve, away from the discharge, and quickly open the cylinder to give it a quick blast. This will dislodge any dirt or particles stuck in the valve or the connection seat. This will help reduce the chance of dirt particles making its way into the solenoid valve, causing sticking issues later on.

Connecting your cylinder will require a cylinder wrench (1 1/16") to connect the regulator to the cylinder (North American Cylinders with a 580 CGA valve). If you do not have a cylinder wrench, an adjustable type wrench will work, but make sure it is properly adjusted to prevent rounding of the fitting shoulders. Do not use pliers, or a serrated-

jawed wrench such as a pipe wrench or basin wrench to tighten the fitting. The design of the fitting means that no thread sealing tape or compound needs to be used.

Connect the regulator tubing to the regulator. The regulator may be supplied with a hose barb connection, or a threaded connection for the tubing (depending upon region). If the regulator supplied has a hose barb, make sure the hose barb fitting is tight on the regulator. Tighten with a 3/4" (19mm) wrench. If it is a threaded connection, use two 3/4" (19mm) wrenches to hold both the regulator and the tubing connection at the same time. Hold counter pressure on the regulator connector while tightening the hose fitting to prevent damage to the regulator and to ensure maximum sealing. After connecting the tubing to the regulator, connect the other end of the tubing to the 5/8" CGA fitting on the unit. Hold the fitting on the unit with one 3/4" (19mm) wrench firmly while tightening the hose fitting with another 3/4" (19mm) wrench.


Important: Do not use thread tape or pipe sealant on any cylinder, regulator or unit connection. The residue and debris may get into the gas solenoid and cause operational issues.

CAUTION!

Do not tighten the rear unit connection without holding the female 5/8 CGA fitting located on the unit with a wrench, or damage may occur to the bezel and the fitting as the fitting may turn in the housing while the hose fitting is being turned.

Connect Regulator To Cylinder And Unit.

Note: Some regulators may have a hose barb connection fitting on the regulator.




Setup Guide

Getting Started

The on screen programming will remind you what polarity to use, but in case you forget, refer to the illustrations below.


SELECT THE CORRECT MIG AND FLUX-CORED POLARITY.

How Do I Change Polarity For MIG?



The MIG gun must also be correct in polarity. Drop open the cover on the left side of the MIG to access the wire spool and feeder. Just above the feeder, there are two terminal lugs. The lower is positive, and the upper is negative. If there are no positive (+) or negative (-) symbols, there may also be a label that says "Gas MIG" and "Gasless" or something similar. Regardless, the lower terminal is positive and the upper terminal is negative. For MIG, the wire feeder cable should be connected to the lower positive (+) terminal via the provided screw. See below.


MIG/MAG Position




Even though similar in concept, MIG/MAG (GMAW) and Gas-less Flux-Cored (FCAW) welding require a polarity change when transitioning between the two. The unit will remind you with an on-screen prompt to change polarity when you change between the processes, but this is an often over-looked issue, even when reminded by the

machine. Failure to change polarity will result in erratic operation, bird's nesting of the wire, poor fusion and excess spatter. Use illustrations below as a guide. **Do not confuse Gasless Flux-Cored (FCAW) operation with a different welding process known as Flux-Cored with Shielding Gas (FCAW-G). Flux-Cored with Shielding Gas (also known commonly as dual-shielded welding) welds with the same positive (+) polarity as solid wire MIG (GMAW).**

How Do I Change Polarity For Flux-Cored?



When welding most all gasless flux-cored wires, polarity will be negative. There are a small number of exceptions. However, if the manufacturer doesn't state the polarity, assume it is negative. Drop open the cover on the left side of the MIG to access the wire spool and feeder. Just above the feeder, there are two terminal lugs. The lower terminal is positive, and the upper is negative. If there are no positive (+) or negative (-) symbols, there may also be a label that says "Gas MIG" and "Gasless" or something similar. Connect the wire feeder cable to the upper terminal lug via the provided screw.




Setup Guide

Getting Started

SELECT THE CORRECT STICK POLARITY.

Where Do I Connect The Stick Torch?



For most all applications, connect the electrode holder to the positive terminal. Connect the work clamp to the negative terminal.

NOTICE: The polarity of the MIG wire feeder does not affect stick polarity or affect the stick welding function. If the MIG gun is removed when welding in Stick mode, the cable connecting the wire feeder (under the cover) to the polarity terminal can remain in place. The terminal is simply a power output point. If, for whatever reason, the gun is not removed, then the wire feeder cable should be detached from the terminal to prevent accidental arc striking which may result in personal injury and/or damage to the machine.

WARNING!


Remove the stick torch while MIG welding to prevent accidental arc striking and damage. Remove the MIG gun while stick welding for the same reason. The stick and MIG gun terminals will remain live despite the mode that has been selected. The power is not disconnected to the output terminals on the machine while welding other processes. Do not touch exposed terminals while welding in either process. If the MIG gun cannot be removed the torch end can be insulated by sliding a rubber hose over the nozzle. Or conversely, the polarity cable under the cover may be unscrewed from the terminal if the gun is left in place. The best option however, is to remove the MIG gun while welding stick. If the MIG gun left in place while using stick mode an arc could be struck accidentally via the MIG gun, resulting in personal injury or machine damage.

Selecting the right stick electrode polarity is simple since most all welding is done electrode positive, regardless of rod classification or brand. The main exception to this is that E6011 may be used DC electrode negative (DCEN), but in most cases it will still be used with electrode positive configuration. Some manufacturer's may additional-

ly rate other classes of their welding rods for all polarities, but the times that you would actually use DCEN is rare.

INSTALLING THE OPTIONAL SPOOL GUN.

Where Do I Install The Spool Gun?



The spool gun connection process is similar to the MIG torch connection and uses the same Euro Quick Connect connection. Polarity configuration is the same as MIG except when Flux-Cored wire is being used. If Flux-Cored wire is being used, then use the standard Flux-Cored polarity.

The **Parker DSP 360 Spool Gun** is recommended for use with this unit and provides the best duty cycle and amperage rating. It's a durable high Amp, high Duty-Cycle Gun. This gun is of exceptional quality and accuracy. It is pre-calibrated to be synchronized to this welder's wire speed read-out. Use .035" or larger wire diameter for best results. Be sure to order the optional drive roll to fit your wire type and size. The stock drive roll size will be .040" or .045" 1.0mm or 1.2mm U groove. Contact Everlast to verify the sizes you expect to need and order them direct. Other guns offered by Everlast do not supply enough power output capacity and duty cycle to be used with this unit.

Setup Guide

Getting Started


CHECK AND CHANGE YOUR DRIVE ROLL.

The unit comes with a pair of .035" and .045" drive rolls installed. Remember, if you change wire size or type, you will need to either flip both of the lower drive rolls over for the opposing size or completely change both of the drive rolls out with the ones of correct size and type found in the consumable bag. When not in use, keep these "spares" put up where moisture and dust cannot get to them. They will rust if not used and stored properly.

The top drive rolls are actually idler rolls used to hold tension and keep the wire in the groove. These are not changeable. Only the bottom drive rolls need to be changed. Each of the bottom drive rolls have two small grooves that are sized for .030" (.8mm) and .035" (.9mm) solid wire. Additional sizes and types of drive rolls are available as options. The standard installed drive roll is meant to feed hard (solid) steel wire. The groove on this drive roll has a "V" shape designed for the solid wire. A Flux-Cored drive roll has a serrated edge to the groove, which grips the softer, cored wire. Viewing a flux-core drive roll from the top, you will see a "zipper" like pattern. This should never be used to feed hard steel, stainless or aluminum wire. This will result in damage to the wire, metal flaking and possible plugging of the MIG gun liner. To determine the exact size of wire and type you have, look at the side of the drive roll. The size of the drive roll groove is stamped on the side of the drive roll closest to the corresponding groove. The type of the drive roll will also be stamped with a V if it is for solid, hard wire. If it is stamped with an "U", this is a special drive roll for feeding aluminum wire. Aluminum wire is best fed with a spool gun.

The drive rolls are held in place by a screw. Use a flat head screw driver to gently remove the screws to expose and change the drive roll. The drive rolls are mounted on a bushing. To prevent the bushing from being removed along with the drive roll, use the index finger of one of your hands to hold the bushing while the other hand removes the drive roll. When removing make sure that the square locating key is not dismounted. If the key falls out of the keyway, replace it before replacing the drive roll. When the drive roll is reinstalled, just lightly snug the screws with the screw driver. Do not over tighten.


Drive Roll Size and Location Info



INSTALL THE WIRE AND FEED THE GUN.

Once the wire spool has been installed, flip the tensioner lever down and raise the top drive rolls to the upper position. See the illustration below. Gently guide the wire from the spool over through the wire feeder and into the front section of the gun at least 6 inches. Make sure the wire lays neatly in the grooves of both drive rolls. Hold it with your finger if necessary as you lower the upper drive roll arm down and raise the tensioning lever into position with your other hand. After the tensioner is raised back to the vertical position, confirm the wire is still in both grooves and is not riding up on the shoulders of either drive roll. Next, turn the welder on and set to a desired MIG or Flux-Cored mode. Remove the gas nozzle by pulling it with a slight twist. Unscrew the contact tip as shown in the illustration below. Use a wrench to hold the contact tip holder so it won't unscrew when the contact tip is removed. Hold the gun cable and gun straight as possible. Press and hold the wire jog button. The wire should slowly begin to feed through the gun cable and eventually through the


Installing the MIG Wire



gun. As the wire exits the gun, allow 3 extra inches of wire to be fed out past the diffuser. Release the wire jog button. Re-install the contact tip over the wire and screw it in clockwise until it is snug. Do not overtighten. Install the gas nozzle.

Hint: The wire on the spool is usually bent and threaded through a small hole in the side of the spool to lock it in place and prevent despooling of the wire. Keep one hand on the wire spool to prevent despooling and cut the wire loose with a pair of wire cutters. Trim the wire to make sure the end of the wire is straight and able to be

How Do I Disassemble the MIG Gun?




Setup Guide

Getting Started

threaded through the wire feeder mechanism and gun.

TRIM THE WIRE AFTER INSTALLATION.

Trim the wire sticking out of the nozzle to 1/4" to 3/8" (6mm to 9mm) in length with wire cutters. See the illustration below. The gun is now ready for welding. *Hint: Always make sure that you re-trim the wire before beginning a new weld if the wire is not already trimmed to this length. This will help to improve arc restarts.*




PROPERLY TENSION THE WIRE FEEDER.

To feed properly, the wire needs to be tensioned before you begin welding. The tensioning lever has numbers on the dial. To increase tension, rotate the tension lever clock-wise. Different types of wires require different tensions. There is no exact tension that works for all wire types. However, for steel wire, you will generally tension to at least 3 to 3.5 on the dial. Wire diameter can affect the tension requirement slightly. Wire quality also plays a small part in the amount of required tension that is needed. Lower quality wire may have slight variations in thickness, causing slippage of the drive rolls at various points, while no slipping is observed at others. For flux-cored wire, it will require a lighter amount of tension. For Aluminum, try 2.5 to 3 on the dial. Regardless of the wire type or wire diameters (and for best results), follow the process below and refer to the following illustration. Turn the unit on and pull the trigger so that the wire extends approximately 1" beyond the gas nozzle.

- Find a small block of wood, such as a two by four, and secure it to the welding table or other solid object. **Do not test this on metal or arcing may occur if the work clamp is connected!**
- Hold the gun approximately 2 inches off the wood. Aim the gun at the block of wood so that the nozzle is at a 30 degree angle to the wood.
- Pull the trigger and allow the wire to contact the block.


- Increase wire tension so that the wire contacts the block of wood and is forced to curl up. Continue holding the trigger so that two or three full spirals are made.
- If the wire stops, or stutters during this process, let go of the trigger immediately and increase tension.
- Adjust the wire until the stuttering or jerking disappears.
- Do not over-tighten the tensioner or use more tension than necessary. When the wire begins to curl without any stoppage, the tension is enough.

Test Wire Tension Before Welding



Component Identification and Explanation


Front Panel View



Number	Component Identification	Component Note
1	Protective Cover	Keep cover down and in place during welding activities and in storage.
2	Euro-Style Quick Connector	Connect this to the MIG gun or Spool Gun.
3	Positive Terminal (+) DINSE 35/50 Type	For Stick, connect to the Torch. For MIG, this remains vacant. For Flux-Cored connect the work clamp.
4	Negative Terminal (-) DINSE 35/50 Type	For Stick connect to the work clamp. For MIG, connect to the work clamp. For Flux-Cored, this remains vacant.
5	Control Connector	For the Spool Gun, the control circuit wire goes here.
6	Handles	Install handle with provided screws. If its use is not desired, you may leave them off and install just the screws.

Component Identification and Explanation

Rear Panel View



#	Component Identification	Component Note
1	Fuse	This fuse protects the wire feeder and certain components from damage. If the wire feeding stops or the machine suddenly powers down without warning, check the fuse. Replace the fuse with the identical type supplied with the machine. Check the marking on the fuse for Amperage and type. Do not replace with smaller or larger Amperage fuses. This is a common type automotive fuse.
2	240V Cooler Outlet	This is a low Amp 240V receptacle. Use only with Everlast 240V coolers. Other use may cause damage or fire. Do not attempt to modify this receptacle or wiring. This outlet is switched via the main power switch and will not supply power while the machine is off.
3	MIG inlet connector	5/8" CGA Inert Gas fitting. This is a standard fitting use for connection of all argon and argon/CO2 gas fittings to regulators in the North American Market. <i>Other regions may vary the type supplied.</i>
4	Input Cable and Plug	The unit may be operated on either 240V 50/60Hz ($\pm 10\%$) 1 phase input power. <i>208V will affect accuracy of adjustment and output. Use a buck-boost transformer if voltage is derived from 208V Wye type service.</i> North American standards require only 3 wires for 1 phase operation of welders. A neutral is not used. For wiring a 1 phase connection to the unit: Use Black for L1, White for L2, and Green for ground (not neutral) use. Red is not typically used in wiring a welder circuit. This is in accordance with North American codes for welder wiring (see Article 630 of the NEC for more wiring info). <i>The supplied NEMA 6-50P is the proper plug used for wiring single phase 240V welders in North America. It should not be changed or removed unless wiring directly into a cut-off switch. Other regions may vary and may have a different plug type or no plug at all.</i>
5	Ground Service Bolt	For use in a combined effort to mitigate any electrical interference that may be caused by the operation of this unit. This should be connected (if needed) to an outside ground rod driven into the soil. Normally this is not used unless interference is observed. If it is needed, this represents an extensive grounding project. First try relocating the welder and affected objects. If no success is obtained, inspect building ground. If nothing is found then All metal objects should be attached to a separate ground outside the shop. Contact Everlast for further details.
6	Breaker/Power Switch.	This switch doubles as the main power switch and disconnect switch. If this switch trips and the welder power turns off, a significant internal event or failure of the switch <i>may</i> have occurred. If this occurs, immediately remove this unit from service and mark/tag according to regulations. Contact Everlast Tech Support for further diagnosis and/or repair options.

Component Identification and Explanation

Control Panel Layout



#	Component I.D.	Component Note
1	Process Selector	Use the left and right arrow keys (◀ ▶) to select the desired welding or cutting process.
2	Display	This color LCD display provides all the information relative to setting the machine and indicating set parameters.
3	Left Adjustment Knob	The left adjustment knob is used to change the desired status of a function (i.e. voltage, turn on/off, electrode type, thickness etc.) and to set all adjustable values to the left side of the black dividing hash mark just above the “EVERLAST” logo. If you push in on the knob while adjusting, it will adjust in larger increments, usually in whole numbers or increments of 10.
4	Left/Right Dividing Hash-mark	This mark divides the functions between left side controlled functions and right side controlled functions of the machine. The left side adjustment knob and navigation buttons control the left side of the machine. The right side adjustment knob and navigation buttons control the right side of the machine.
5	Gas Purge	This is used to set gas flow rate without having to use the torch trigger. This prevents live feeding of wire.
6	Wire Jog	This “cold feeds” the wire through the machine to assist in threading the wire through the drive rolls and into gun without danger of striking an arc.
7	Left Side Navigation	Use the up and down arrow keys (▲ ▼) to navigate and select the parameter on the left side of the hash mark that you wish to change or adjust. The actual direction may go either up and down or left and right, depending upon the function level you are adjusting or selecting.
8	Right Side Navigation	Use the up and down arrow keys (▲ ▼) to navigate and select the parameter on the right side of the hash mark that you wish to change or adjust. The actual direction may go either up and down or left and right, depending upon the function level you are adjusting or selecting.
9	PowerSet	The PowerSet function, when selected, enters a synergic mode which gives automated settings based off of the diameter of electrode, type of metal, type of gas, and thickness you input into the unit. This simplifies operation and reduces the knowledge base needed to make the correct adjustments needed to weld properly. When PowerSet mode is selected, some functions of the machine will be set to automatic and will not be adjustable.
10	Run-in	Run-in uses a slow wire feed in before and as the arc starts to help improve arc starts and prevent excess stuttering (machine gunning) of the wire at the start. This acts as a sort of “hot start” to prevent porosity and cold welds. If turned off, the wire will feed quickly at the set wire speed as the arc starts. This can create harsher starts in some situations.
11	Right Adjustment Knob	The right adjustment knob is used to change the desired status of a function (i.e. Wire Speed, Amperage, Spool-gun operation etc.) and to set all adjustable values to the right side of the black dividing hash mark just above the “EVERLAST” logo. If you push in on the knob while adjusting, it will adjust in larger increments, usually in whole numbers or increments of 10.
12	Save Program	The save program feature allows the user to save programs in both MIG and Stick modes. To begin, set the machine up as desired. Next to access the programming function, press the program/save button and the save screen will appear. Use the up and down arrow keys (▲ ▼) to select the number where the program will be saved. Once highlighted, press and hold the save button for three seconds. This will automatically save the program and the new program description will appear. You can save over old programs or test programs entered at the factory if desired. Always keep a record of the program number.

Component Identification and Explanation

Getting Ready To Weld

GENERAL INFORMATION ON SETUP AND USE.



Selecting the Process.

At the top of the panel (1) the process selector is used to select the desired welding or cutting process. Use either the right or left arrow (◀▶) buttons to advance to the next process. Pressing the left or right arrow button rapidly will require the button to be pressed twice to move to the next process. The initial press of the arrow button will display the polarity screen for the next process. A rapid second press abbreviates the polarity screen (see next page) and allows you to enter directly into the setup screen for the process selected. A third rapid press advances to the next process polarity screen. However, if you advance slowly or decide to move to the next process after the machine has had time to automatically advance to the setup screen, it will only require one press to advance to the next process. If you accidentally pass the process you wanted, instead of cycling back through all the processes, simply use the opposite arrow button to scroll back to the process you desire.

Navigating the Menu.

The panel is divided in half by a black hash-mark (2) below the screen and a green vertical bar down the middle of the screen. This divides the control region in half. The left side up and down (3) arrows (▲▼) controls the left half of the screen and the right side up and down arrows (▲▼) controls the right half of the screen. Both functions (items that may change in status, such as ON/OFF, or Gun Selection), and parameters (items that change in value in a range such as inductance percent) are selectable with the arrow buttons. The arrows are used to scroll through and highlight the selected function or parameter. When a function or parameter is selected and available for adjustment, it will be highlighted and change color, turning from gray to green (3). In some modes, to avoid confusion, the general area that is navigated to will flash as well. Default selection will always be the main adjustment on that side (Volts/Amps/Wire Feed Speed etc.) (5). When navigation is in default mode, the main parameter will be brightly lit in white (or green for voltage in stick, see stick setup section). When navigating away from the default pa-

rameter area, the large white numbers will appear to dim. After 4 to 5 seconds if you haven't made another selection or made an adjustment to the function or parameter selection, the machine automatically defaults back to the main parameter area and the numbers will brighten and will be able to be adjusted. Of course, if you continue to navigate completely through the left or right side functions and parameters, you will eventually cycle back to the default parameter area (voltage, wire speed, amperage etc.) and the numbers will brighten to indicate that you have fully cycled through all the parameters and returned to the default. **NOTE:** If a parameter or function (4) has a black background (STD.) this function or parameter cannot be selected, changed or adjusted due to the mode or setting you selected (i.e. PowerSet) the function is either not relevant or is automatically set by the machine.

Changing the Functions and Adjusting the Parameters.

To change the status of a function or adjust the value of a parameter, use the left or right up and down arrow keys (▲▼) to navigate and highlight the desired function or parameter. Then, use the left or right control knob (6) to make the change in function status (change from OFF to ON, or change torch type, etc.) or change in parameter value (increase or decrease the amount of seconds or percentage etc.). As a default, without navigating to the desired function or value, the left and right control knobs will be used to adjust the Voltage, IPM, or Amperage. **NOTE:** When in Stick mode, the left display will display voltage, but due to the nature of constant current stick welding, voltage is not adjustable and is controlled by the arc length.

Observing the Important Information.

At the top center of the machine (7), the welder will display important reminders to change gas, or which process is being used. It will also tell you, in case you forget, whether you are in manual or PowerSet mode. The input voltage is displayed as a confirmation and reminder of the correct input voltage. Run-in status is also displayed as "Run-in On" or "Run-in Off".

Saving a Program.

To save a program, the welder should be set to desired parameters. Once desired parameters are set, press and release the PRGRM/SAVE/RECALL button (8). When the save screen opens, use the corresponding left or right up and down arrow keys (▲▼) to navigate up and down to the desired program number. When the desired number is highlighted, press and hold the PRGRM/SAVE/RECALL button for 3 seconds to save the settings. When released, the program will be saved the process information will be displayed on the program number line. In some cases, when new the program page may have a few programs already entered for testing purposes at the factory. These programs may be saved over if desired. The test programs are not meant to serve as useable programs or default programs for the user. Similarly, old programs no longer needed may also be saved over. To access a program, press and hold the

Component Identification and Explanation

Getting Ready To Weld

PRGRM/SAVE/RECALL button to return to the program screen. Use the navigation buttons to highlight the desired program. Quickly press and release the PRGRM/SAVE/RECALL button to recall and open the program. If the program needs to be fine tuned, the settings may be adjusted or changed while in use. However, if changes are made to the program, unless the program is resaved, these settings will not be automatically saved to the program. To save the changes, repeat the save program steps.

IMPORTANT: When recalling a program, do not press and hold the button or the program may be erased or saved over with the current settings of the machine. Simply press and release the button.

Program	
1a. _____	1b. _____
2a. _____	2b. _____
3a. _____	3b. _____
4a. _____	4b. _____
5a. _____	5b. _____
6a. _____	6b. _____
7a. _____	7b. _____
8a. _____	8b. _____
9a. _____	9b. _____

Component Identification and Explanation


Setting the Unit Up For Welding Manually

THE WELCOME/BOOT SCREEN



When you first turn the unit on with the rear power switch, this screen will greet you as the machine begins the boot process. Simultaneously, all the process selection LED's should be lit on the control panel.

THE POLARITY SCREEN




After the boot process (2 to 3 seconds) completes, the unit will briefly display a polarity reminder screen (4 to 5 seconds) as depicted above. Simultaneously, the welder should highlight the last process used by lighting one corresponding red LED at the top of the panel in the process selection area. **NOTE:** In the left column of the screen, during any wire feeding mode, the unit also reminds you to check and change your polarity connections of your wire feeder, indicated by the terminal lug and blank terminal. A reminder to use gas (MIG), or not to use gas (Flux-Cored) is also displayed for wire feeding modes. MIG will also display a "Run-In" indicator for slow wire start for improved starting if selected. For Stick, a similar polarity reminder appear as well. It's especially important to check and change your torch and work clamp polarity or improper operation and even damage to the machine may occur. As a best practice, keep the torches disconnected until the polarity screen displays to prevent damage to the machine. Also be sure to remove the torch before changing polarities. Do not try to operate the machine with more than one torch connected at a time.

If desired, at this point you may change the process by using the up/

right arrows (◀ ▶) at the top of the panel to select the desired process. Be sure to wait until this screen is present before you attempt any change of the welding process. Any time you change processes, the screen will reappear briefly to remind you to make any required changes to polarity.

THE MAIN CONTROL SCREENS (MANUAL MODE)



MIG/Flux Cored Manual Screen

1. **Welding Voltage.** Adjust with Left adjustment knob. Select with left up and down arrow keys. When the Voltage is selected for adjustment, the numbers will brighten in color. This is the default setting of the left side. After 5 seconds of no input or adjustment of other parameters or functions, the selected setting will default back to the Voltage.
2. **Voltage Input Confirmation.** This confirms which voltage the machine is being supplied. This also serves as a diagnostic tool. If the machine does not show 240V while operating on 240V, then the power supply to the welder is likely faulty. **NOTE:** Maximum output of the machine is governed by the input voltage. Some selections may not be possible on reduced input power.
3. **Gas/Process Reminder.** This reminds the user which gas or process has been selected. It will display either C25 (75/25 Ar/CO2 for Steel), C100 (100% CO2 for Steel), Mix Gas (98/2 Ar CO2 for Stainless/Inox), Ar Gas (100% Argon for Aluminum), or No Gas (For Flux-Cored on Steel) in wire feeding modes.
4. **Manual/PowerSet Mode.** This indicates which mode the machine is operating in, whether in full manual mode or in PowerSet mode which is a synergic, more automated mode. In PowerSet, many functions may not be available for adjustment. (See the MIG PowerSET section).
5. **Run-In On/Off.** Run-in provides a low speed start for the wire until after the arc is started. This improves the arc starting ability. This indicator reminds you whether you have it selected or not.
6. **Wire Feed Speed Indicator.** Adjust with Right adjustment knob. This indicates the wire feed speed in both Inches Per Minute

Component Identification and Explanation

Setting the Unit Up For Welding Manually

(IPM) and in Meters Per Minute) m/Min. This is the default setting for the right side. After 5 seconds of no input, When the Wire Feed Speed is selected for adjustment the display will brighten in color. This is the setting. After 5 seconds of no input or adjustment of other parameters or functions, the selected setting will default back to the Voltage setting.


7. **Up-Slope and Down Slope.** These two functions are linked in function. Up Slope provides a time duration for wire speed to accelerate from the Start Wire Feed Speed (Start WFS). This can be used to further improve arc starting when used with run in and should exaggerate the hot start feel. The Down Slope provides a time duration for the wire speed to ramp down to the preset End Wire Feed Speed (End WFS). This provides time for the welder to fill the crater instead of the arc abruptly terminating and leaving a crater at the end of the weld. In 2T, the arc will start slow and accelerate up to the welding wire feed speed automatically. In 4T, the trigger should be depressed and released quickly, as soon as the arc starts, to allow the Up Slope to function and accelerate the wire speed. If the trigger is held the Up-Slope will be delayed until the trigger is released. Note that Down Slope will keep the wire feeding briefly after the trigger is let go in 2T if a time value is set more than 0.0 seconds. In 4T the trigger is depressed and held to control the actual arc termination, or is depressed and let go quickly to automatically allow the wire to decelerate to the End WFS. If one or both of these functions are not desired, select 0.0S. In PowerSet mode these functions are managed automatically and will be non-adjustable. If manually rapid tacking or spot welding select 0.0S for both.
8. **Start and End Wire Feed Speed (WFS).** The Start and End Wire Feed functions (Start WFS, End WFS) allow the user to set a pre-determined wire feed settings at the start and end of the weld. At the Start of the weld, if being used, a lower setting creates a smoother start with less popping and spattering typical of cold starts. The reduction of the sputtering (also known as "machine gunning") will be noticeable at lower settings than used to weld. End wire feed speed is designed to be used to fill the crater at a lower Amperage/WFS to help prevent stress in the weld. If in doubt about the best setting for either, always start at the minimum Start and End WFS setting for the smoothest starts. Or, for general purpose welding set both to 60% to 75% of welding wire feed speed and fine tune it as desired.
9. **Pre-Flow.** The unit has an adjustable pre-gas flow setting. This automatically times the flow of gas before the weld, improving overall weld quality at the critical start of the weld. However, the user may opt to turn down this setting if desired Use the left Up and Down navigation keys to navigate and highlight (turn green) this setting. Use the left adjustment knob to turn the setting on or off. In Flux-Cored mode, this feature will be unavailable and be listed as N/A.
10. **Post Flow.** The unit has an adjustable post-gas flow setting. This is complimentary to the Preflow setting and also serves to improve the weld quality and prevent oxidation after the weld is terminated and also serves to provide gun cooling. However, the user may opt to turn down this setting if desired Use the left Up and Down navigation keys to navigate and highlight (turn green) this setting. Use the left adjustment knob to turn the setting on or off. In Flux-Cored mode, this feature will be unavailable and be listed as N/A.
11. **Inductance.** This improves the wet in of the weld. A low setting will result in a very poor arc, with a high pitch. The result will be a raised ridge in the middle and poor wet-in. Excess spatter may be observed. The result of too high of a setting will result in a very fluid, flat puddle. The pitch will be raspy and not smooth. Starts will not be as smooth Generally a setting of 65 to 75% is a good starting point on Steel with C25. With Steel and C100, 70 to 80% is a good starting point. Generally pure CO2 is not very smooth on many welders, but with inductance control, high quality welds can be achieved. Stainless requires the highest inductance with 90% or greater. Aluminum can range depending upon the wire from 60 to 80% or so. Flux-Core behaves a little differently with a 40 to 50% starting point. Of course, different weld positions, joint designs and thicknesses of metal can affect the inductance requirement slightly. Use the left Up and Down arrow keys to navigate and highlight (turn green) the Burn Back control. Use the left side control knob to change the value.
12. **Burn Back.** This is the amount of time the arc stays on after the wire stops feeding. It is used to help prevent the wire from sticking in the weld and to reduce the need for constant trimming of the wire before restarting. Use a setting of .1 to .3 seconds to begin with for most applications. Smaller diameter wires need less burn back time. Use the left Up and Down navigation keys to select and highlight (turn green) the Burn Back feature. Use the left adjustment knob to adjust the duration of the Burn Back.
13. **Spot Timer.** This is a timer that can be set to automatically shut off the weld when the trigger is held down. This allows you to make repeatable and perfectly sized tack welds or short seams. Use the Right side Up and Down navigation keys to navigate and highlight (turn green) the Spot Timer. Use the right side adjustment knob to turn the Spot Timer on and set the duration of the spot timer. **NOTE:** Keep in mind that If the spot timer is turned on accidentally, the wire feed will stop suddenly soon after the trigger is pressed. In fact it may barely feed and just seem to quit if the time is set low. This is normal, but often a source of tech support calls. If your wire feeder stops feeding unexpectedly after the trigger is pressed, check this function first.

Component Identification and Explanation

Setting the Unit Up For Welding Manually

- 14. Stitch Timer.** This function works only in conjunction with the Spot timer. This provides a continuous “on/off” action of the spot timer, allowing the user to move smoothly and evenly space spot welds along a seam or around a part, providing “stitches”, or a series of tack welds. The time set is the length of “OFF” time between the Spot cycles. The trigger will be held down and the spot/stitch cycle will continue until the trigger is released unless the unit is being used in 4T mode in which case the trigger will be pressed and released and the cycle will begin. A second press of the trigger will be required to terminate the cycle. (See next item for 2T/4T explanation.)
- 15. Torch Trigger Function.** This controls how the welder reacts to the torch trigger. In 2T, the trigger is pressed and held to weld. In 4T, the trigger is pressed briefly to start the arc, then released to continue to weld. The weld is continued without the torch trigger being held down. The trigger is once again pressed, held and then released to terminate the arc.
- 16. Torch Type.** Select between the main MIG gun or Spool Gun function.
- 4. Manual/PowerSet Mode.** This indicates which mode the machine is operating in, whether in full manual mode or in PowerSet mode which is a synergic, more automated mode. In PowerSet, many functions may not be available for adjustment. (See the Stick PowerSET section).
- 5. Amperage.** The Amperage is adjusted by the right side adjustment. This is the default setting. If no adjustment is made to selected functions or parameters, the machine will automatically default back to the Amperage setting after 4 to 5 seconds.
- 6. Arc Force %.** The arc force function only works in Stick mode. Arc force is used to offset the loss of overall wattage ($V \times A = W$) as arc length is shortened and voltage begins to drop while stick welding. It offsets the drop in voltage by injecting extra amps into the weld when voltage drops below 20V. This enables the amperage to react aggressively or mildly, depending upon settings, to prevent arc outages, and allowing the user to hold a tight arc and maintain better control.
- 7. Hot Start %.** This adjusts the intensity of the start. When welding this helps to prevent electrode sticking and helps to eliminate porosity at the start of the weld. Hot start intensity is the percentage over the set amps at which the Amps will be boosted during the arc start.
- 8. Hot Start Time (S).** This sets the amount of time the hot start stays engage at the beginning of the weld.
- 9. VRD.** This is called the Voltage Reduction Device. It is a safety feature designed to help reduce chance of shock or electrocution. This lowers the OCV of the machine helping to reduce the chance of accidental shock or electrocution while welding where the user may become a part of the circuit path of the weld. This may be required in some situations by regulations. This will increase arc starting difficulty on some rods. If this is not required, or the conditions exist where the user is perfectly insulated from the work and the possibility of becoming a part of the circuit path is low or eliminated, it may help to turn this setting to “OFF”. To help start the arc while the VRD is on, a quick double tap will help to strike the arc instead of the single scratch or tap.
- 10. Standard Mode.** This mode is to be used with all stick electrodes **except** electrodes with a cellulose-based flux, i.e. 6010, 7010, 6011 etc. It provides a softer arc, with low spatter and a smooth bead appearance.
- 11. Cellulose Mode.** This mode is to be used with welding electrodes including 6010, 7010, 8010, 6011. It provides a more forceful, penetrating arc. When combined with hot start and arc force, this setting will make the arc more aggressive and help with maintaining a key hole in root pass welds. As a general rule keep the arc short as possible to prevent arc outages.

THE STICK MANUAL SCREEN



- 1. Welding Voltage.** In Stick Mode, the Voltage is not adjustable due to the nature of stick (Constant Current) welding. The voltage varies according to the length of the arc. The Voltage displayed while idling is the Open Circuit Voltage (OCV) of the machine. While welding this changes to reflect the actual arc voltage.
- 2. Voltage Input Confirmation.** This confirms which voltage the machine is being supplied. This also serves as a diagnostic tool. If the does not display 240V, then the power supply to the welder is likely faulty. **NOTE:** Maximum output and accuracy of the machine is affected by voltage lower than 220V.
- 3. Process Reminder.** The process reminder displays “Stick” when stick mode has been selected.

Component Identification and Explanation

Setting the Unit Up PowerSet Mode

UNDERSTANDING POWERSET.


The PowerSet mode, regardless of process selected is designed to help the user make accurate settings without the aid of complicated charts or calculators. This helps both new welders and professionals to set the machine easily without an extensive trial and error process.

The synergic nature of PowerSet mode requires the user to input certain basic information (depending upon the process) such as metal thickness, electrode diameter, wire type, and gas type. Once entered, the machine takes over from there and presets a setting that is determined mathematically from the information given.

While PowerSet is a useful tool, not every possible scenario can be predicted. It does a good job at getting close to the right setting (in most case, it will be very accurate). But things like weld position, joint design, and even certain welding styles can create a situation where the programmed setting is not perfect. In these cases, the PowerSet allows the user to fine tune the settings. However, there is a limit to adjustment that is allowed in the PowerSet mode to prevent an unworkable setting. There is usually a sufficient amount of adjustment provided to allow the user to find the perfect adjustment. *However, in the event the user cannot find the perfect setting in PowerSet mode or is unhappy with limitations placed on other functions or modes, the user should leave PowerSet mode and configure settings manually.*

USING POWERSET MODE.

Starting PowerSet Mode



To use the PowerSet mode, first select the process you wish to use, paying attention to the type of gas/metal you are welding. Then, once you have properly set the process, select the Power Set Button at the

bottom right side of the panel by pressing the button briefly. The LED above the PowerSet button will illuminate. This will activate the PowerSet Screen for the process you are using. (Each process allows the use of PowerSet.) Once activated you will be ready to begin entering the information you need.

Using PowerSet Mode.



Keep in mind that if you don't enter the correct information into the machine, you will not get correct operation either. Always review the information you've put into the machine before deciding the unit isn't working correctly or there isn't enough adjustment to provide the proper setting.

Regardless of the Process, the PowerSet mode essentially functions the same. The above image is the PowerSet mode as it appears in the MIG C25 process. Each process is slightly different with which functions and parameters are allowed to be set, but otherwise setup procedure is nearly identical. Begin the setup process by using the up and down arrows (▲▼) on the *left side* to navigate to the "Work Thickness" (1) level. Rotate the *left side* adjustment knob to select the thickness of the metal you are welding, or the closest thickness/gauge if not listed. Continue the setup process by using the up and down arrows (▲▼) on the *right side* to navigate to the "Wire Diameter" (2) (Each mode varies whether its electrode size or wire diameter that is to be selected). Use the *right side* adjustment knob to select the correct size. **NOTICE: In some cases, selections may be limited because it is beyond the capacity of the electrode size or wire diameter to properly weld or** Once the information has been entered, the machine will automatically set your welding or cutting parameters for you and will be indicated by the center adjustment bar in the stair stepped indicator below the parameter (3). The bar will have a 4 pointed star to indicate this is the target setting and will be highlighted green. If you need to fine tune the setting, the location of the green bar will move left or right down the "stairs" to the next lower level, (depending upon whether you are increasing or decreasing the value). If you move further than is recommended, the bar and num-

Component Identification and Explanation

Setting the Unit Up PowerSet Mode

bered value (4) will turn red. If you find that you have moved too far off the suggest setting of the machine, all you will need to do is turn the adjustment knob until you are back at the center, tallest bar. Once you are back at the suggested setting, the white 4 pointed star will reappear.

If you need to make any changes to the functions, use the up and down navigation arrows to navigate to the bottom of the menu and to the function. Most parameters will be on a black or neutral background and display either "AUTO", "N/A", "No" above them. These will be blocked from access and will be automatically set for you. If you desire control of these settings, then deselect the PowerSet mode and use the manual mode. **HINT:** If you are concerned about loosing the PowerSet mode to access and control things such as Pre/Post Flow or Inductance, simply copy the suggested settings into manual mode. You are then free to make any adjustment you need to any parameter or function permitted.

In Stick PowerSet mode, you will notice different restrictions on rod size selections that are allowed with different rod types. This is normal. The welder's programming takes into the account the normal min/max range of each class and size of welding rod and it's respective capability at any given amperage.

Why Are Some Settings Limited or Blocked?

The reason that some settings are blocked on this unit is that the machine is in PowerSet mode and is automatically presetting the unit for you and with some input parameters, some settings are not appropriate for the values or operating parameters chosen. For example, if a wire size that is too small is chosen, it may limit certain thicknesses and block you from selecting the full range of thicknesses. In manual mode, most all functions are available for adjustment. If a setting is blocked in manual mode, it is a non adjustable setting.

Component Identification and Explanation

Explanation of MIG Functions and Terms

EXPLANATION OF WELDER FUNCTIONS

Volt and Amp Settings

When welding, the two main functions that require adjustment are Voltage and Wire feed speed. The function of voltage in MIG welding is to control the overall width and to a great extent, the height of the weld bead. In other words, voltage controls the bead profile. It controls wet-in at the toes of the weld, and arc length. Short arc lengths provide wider welds. The wire feed speed directly controls the amps, and in turn amps control penetration. When setting the welder up you will notice that the wire speed is displayed in Inches Per Minute. The relationship between wire diameter, wire speed and amps is easily figured with the following approximate industry conversions:

.023": $3.5 \times \text{Amps} = \text{Inches per minute (IPM)}$

.025": $3.1 \times \text{Amps} = \text{Inches per minute (IPM)}$

.030": $2 \times \text{Amps} = \text{Inches per minute (IPM)}$

.035": $1.6 \times \text{Amps} = \text{Inches per minute (IPM)}$

.045": $1 \times \text{Amps} = \text{Inches per Minute (IPM)}$

To convert wire speed (IPM) into approximate Amps, use the following conversion formula:

.023": $\text{IPM} \div 3.5 = \text{Amps}$

.025": $\text{IPM} \div 3.1 = \text{Amps}$

.030": $\text{IPM} \div 2 = \text{Amps}$

.035": $\text{IPM} \div 1.6 = \text{Amps}$

.045": $\text{IPM} \div 1 = \text{Amps}$

Keep in mind these are approximate conversions and do fall off in accuracy as amps are increased into the upper current limits for the given wire diameter.

Even though you will find general recommendations about setting the Amps, Volts and even shielding gas through a variety of free downloadable apps and online calculators, every filler metal manufacturer has its own specific parameters for Volt and Amp settings for each wire diameter and class of wire. The ranges of volt and amp parameters generally varies somewhat from brand to brand, so be sure to read the packaging and/or manufacturer literature to determine what range of settings are recommended. The wire diameter also limits the practical maximum thickness of what can be reasonably welded. The issue with following charts, graphs and calculator recommendations is that most people find them either too hot or too cold. For some people, it may not be close to the setting they are used to. However, nothing can substitute for watching and listening to the arc. If the arc is correct, a steady sound, similar to the sound of

bacon should be heard. The actual frying sound can vary somewhat and may have somewhat of a higher pitch whine to it. If these sounds are present, look at the arc to see if it is steady, and producing low amounts of spatter. If large amounts of spatter are present, the puddle seems fluid (appears wet) and the wire speed is within the targeted range, decrease volts a little at a time to reduce the spatter. If this does not correct the problem, change the torch angle and torch height. Hold the torch more vertical, with less than a 15 degree deviation from vertical and reduce stick-out of wire to 3/8" or less. If this still does not help, reduce the wire speed. Some spatter is normal, though it should be minimal overall.

The wire can also pop and spatter if the voltage is too low for the wire speed and/or wire diameter. This is mostly observed as flying bits of red-hot but un-melted wire, along with popping as the wire inconsistently stubs into the puddle. This is followed by the wire pushing back against your hand pressure while the wire visibly turns white/red hot before burning off. Too low of voltage will also produce a high piled bead with the toes (edges) of the weld not properly wetting in resulting in poor fusion.

Even though the PowerSet feature has been provided, sometimes additional adjustment may need to be made based off of welding position or joint type. With this unit, we've tried to provide plenty of adjustment range in the PowerSet function. Normally, this will still allow a functional setting. However, when the welding wire is pushed to its maximum limits with Volts and Wire Speed limit, welding may not be smooth and spatter, undercut, and burn back (when the wire melts back to the tip) may occur.

Starting the Arc and Welding In the MIG Process.

Starting the arc is a relatively simple process. Before beginning, the wire should initially be trimmed to between 1/4 to 3/8". Once the wire is trimmed, the gun should be firmly grasped to prevent a phenomenon often referred to as "machine gunning". A light grasp, especially at start, can cause the arc to stutter as the wire pushes back on the gun, lengthening the wire stick-out and creating an irregular start and a porous weld.

The end of the wire should be positioned just barely above the metal when the trigger is pulled for the cleanest start. This will position the end of the contact tip about 1/2" above the weld. The gun should be in the vertical position, with no more than 5 degrees lean in either side to side direction.

Holding the wire too far off from the metal will result in rough starting and too long of wire stick out.

Once the arc has been established, the gun can then either be pushed or pulled in the direction of the weld. In either case, the gun nozzle should be positioned directly over the weld without angling the wire to one side or the other of the weld as already mentioned. The gun should have no more than 15 degrees lean pointed into (push) or pointed away from (pull) the direction of travel. In most cases a push motion is desired. However, a lot of texts offer conflicting information on whether to push or to pull the gun. In reality, both are correct if used correctly and with each having particular strength and weakness. Either one done with too much gun angle will result in undesirable results. Most open-minded people who are

Component Identification and Explanation

Explanation of MIG Functions and Terms

well versed in MIG quickly develop a sense of when to push and when to pull the gun. Even for novices, a sense of when to push and pull the gun comes quickly with a little practice. Pushing can result in shallower penetration but the molten puddle is easier to see and the arc sits easily on the leading edge. It will usually leave an aesthetically pleasing bead. However, be careful to prevent the gun from leaning toward or away from the direction of travel too much as spatter will increase and shielding gas flow may become turbulent, creating porosity in the weld. Pulling will result in deeper penetration, but can result in a narrow bead without much side fusion. It also can leave an undesirable humped appearance if not done correctly or if travel is too slow. **Whenever MIG welding with Aluminum, whether with the standard MIG gun or the Spool gun ALWAYS push the gun. If using Flux Cored wire, a dragging motion is almost always recommended.**

Weaving in Welding. Weaving (oscillating the torch or electrode from side to side in one pattern or the other), particularly in MIG, is a topic of controversy as much as whether to push or pull the MIG gun. Stringer beads are often best for novice welders. Stringers are simply straight beads that move forward with little or no side to side travel or oscillation. These will offer the soundest welds for a beginner in MIG or Stick. Stringer welds leave little or no room for contaminants to enter the weld and are the fastest to produce without creating an opportunity for cold lap. Moving too quickly however with a stringer can create undercut which will weaken the weld. The best policy is to move at a slow steady speed, making sure the sides of the weld are filled. If undercut is present, it is either from too much voltage or moving before the wire has time to fill the area the arc has melted.

Think of weaving as a method of "sewing" the metal together. If weaving is of interest to you, start with the basic weave pattern. Simple weaves using one variation or the other of a cursive "e" motion are best to begin with. Other weave patterns can be used of course. C's, V's, U's, Triangles and many more weave patterns can be used depending upon the application. Weaves are employed for a number of reasons. Weaves are often considered to have a more pleasing appearance and can help bridge gaps where fit up is a problem. A weave is also frequently used to manage heat build up. For example: when welding vertically weaves are almost always used to prevent the molten metal from sagging due to the force of gravity. The major drawback of weaving is that it introduces a greater possibility of getting inclusions and other forms of contamination in the weld. Properly done weaving is a valuable tool, but it must be practiced before employing it in any structural or critical application.

Metal Cleaning.

MIG and TIG welding requires a well prepped surface to obtain a sound weld. The removal of paint, rust mill scale, or other contaminate such as grease should be done before welding. Stick welding is more forgiving of

rust and mill scale, but when MIG welding, contaminants will result in porosity and inclusions in the weld, weakening it. In TIG welding it can be disastrous. TIG requires the most cleaning effort. A grinder will usually prep the metal sufficiently to remove oxidation and paint. However, to remove grease a degreaser such as acetone should be used. Do not use any degreaser such as a brake cleaner with chlorinated solvents or death or serious injury may occur!

MIG and TIG filler wires such as ER70S-6 or ER70S-2 include a sufficient level of deoxidizers such as silicone and copper that are formulated to allow it to handle minor to moderate amounts of rust and mill scale. These deoxidizers will float out most moderate amounts of contaminants out of the weld and will appear in the usual form of glassy like deposits on top of the cooled metal. They are easily brushed off before starting the next pass. They should not be welded over. Any pinholes that appear are a result of trapped gas in the weld and should be ground out before the next pass. It should be noted that some MIG wires such as ER70S-3 have low levels of deoxidizers and must be thoroughly cleaned and ground before welding. MIG and TIG ER70S-2 and ER70S6 are the same except that TIG wire is cut to lengths and MIG wire is continuous. When welding fine gauge materials in TIG, you can substitute sections of thinner MIG wire.

Multiple Pass Welds.

One of the common misunderstandings that people have when beginning to weld is that if the welder has the power, then a single heavy pass should be used to weld it up. This is wrong. This technique is a good way to induce cold-lap and inclusions into the weld. Single pass welds should not exceed 1/4" even with the heaviest wire the welder is capable of handling. A thick pass may also begin to cool before contaminants and gas pockets have the time to float out to the surface. It's far better to make multiple smaller passes to complete a plate weld for a higher quality result. For best results, this requires that most joints 1/4" and over be prepared with a grinder to accept multiple weld passes. The weldment edges should be ground to form a V, U or J shaped groove to create a recess where the welds can be welded one on top of another. For welding with .035" wire and under, create a bead no thicker than 3/16" in a single pass, no more than 1/8" with .030" wire, and with .025" wire and smaller no more than 3/32 for best results. This will help maintain proper fluidity of the weld and prevent gas from being trapped in the weld and give time for any minor contaminants to float out of the weld. It will also help to maintain reasonable forward travel speeds. Too slow of travel speeds will create excess build up and can tend to create cold lap at the weld toes

NOTICE:

This unit features a slow run-in when turned on. This means the wire will feed slowly until the arc is started. It is used to improve arc initiation and reduce weld porosity which results in poor fusion during the arc starting process. Once the arc is sensed, the wire speed will ramp up and weld at the selected wire speed.

Component Identification and Explanation

Explanation of MIG Functions and Terms

resulting in poor tie in. One issue created with a weaving technique even if the metal deposited is the correct thickness is that it can slow the forward progress down. If weaving is too wide, one side of the puddle will cool and oxidize before the torch is brought back across to that side. This is a point where porosity can be introduced.

What Are the Different Kinds of Welds?

Besides a butt joint (Flat edge to flat edge) and lap joint (overlapping edges) which are often used for thinner metal gauges, consider using one of these groove joints for best welding results. When grinding or cutting the bevels, especially with a single V-groove, it may be beneficial to leave a small land with a gap between the joint to achieve full penetration. In this case a temporary backer plate can be used to support the bottom of the weld to create the root pass. The root weld will weld the backer to the main plate. This backer can later be ground or cut off. However, in many cases a plain open root can be used as a backer plate adds to the time and labor involved. A knife edge is also acceptable so long as the joint is fully penetrated when the weld is completed. Open root gaps without a backer can range from 1/16" to 1/8" depending upon wire diameter and application.


When Do I Use Multi-Pass Welds?

When welding material 1/4" and over be careful about trying to put too much metal down in a single pass. Use multiple passes to complete the weld along with any necessary joint preparation especially with wires of smaller diameter. As metal thickness goes up so does the number of required passes. Depending upon the wire diameter and power settings used, a 1/4" joint may only require 1 or 2 passes, but a 3/8" joint in plate metal or pipe will require not only beveling but 4 to 6 overlapping weld passes including a cap and root pass. See Example below.

Joint Preparation



Weld Pass Examples










Component Identification and Explanation

Explanation of MIG Functions and Terms

Drag or Push?

MIG Welding is fairly simple if you keep travel angle and direction in mind when welding. See below. If you are welding flux-core, the gun direction is reversed. **Remember: If it has gas, you use a push angle. If it is gas-less you use a drag angle.** *The old welder's saying "If it has slag, you drag." applies to Flux-Cored Wire welding.*

	Problem Technique: The Gun is not being held vertical from side to side. Wire is not being directed to the center of the puddle. This concentrates heat on one side of the joint and results in poor fusion on the neglected side. It also can create more buildup on one side of the joint than the other. Correction: Hold the gun so that the angle of the neck stands perpendicular from side to side.	
VERTICAL 	Correct Technique: The gun is held in a near vertical position. A variance of 5 degrees or less is acceptable from side to side. The purpose is to prevent the arc from being concentrated on one side of the weld joint or the other. This balances the heat on both sides of the joint and keeps the bead centered. Don't confuse this with push or pull angle in the travel direction.	
 PULL $\leq 15^\circ$	Correct Technique: The gun is angled toward the back of the weld when traveling forward. This angle should not exceed 15 degrees. This provides a narrower but more deeply penetrating weld. Use this method when Flux Core wire is being used. Use this method where the unit may be reaching its maximum welding capacity. Not for use with Aluminum wire.	
 PUSH $\leq 15^\circ$	Correct Technique: The gun can be angled toward the front of the weld when traveling forward. This angle should not exceed 15 degrees. This provides a wider and generally more pleasing weld. However it is shallower penetrating. This method typically allows a much better view of the arc. Use for most types of welding unless deeper penetration must be achieved.	

INNOTECH 36 Series MIG Torch Parts Breakdown (MB36KD Style)



NOTICE:

To change the liner:

- 35

Component Identification and Explanation

Stick Welding Information

STICK ARC STARTING METHODS

1. Make sure the unit is turned on and the boot cycle has finished.
2. Select the Stick Process on the Selector.
3. Make sure the electrode holder is in the Positive connector and the work clamp is in the negative connector.
4. Select the Amp level desired. No voltage adjustment is available. Select Hot Start Time and Hot Start Amps % (Intensity) to improve starting reliability. Use higher amounts of Hot Start %, over 50% with difficult to strike rods, or rods that aren't fresh or out of a sealed metal can.
5. Use the arc force control to select the desired arc characteristics, creating the desired arc characteristic and amp response needed to maintain the arc. Cellulose electrodes may not have the same arc force behavior as other welding electrodes, but each brand and size will weld a little differently. Typically rods such as the E6011 will require a setting 60-80% for best results. The arc force control setting will vary from person to person as well, with different rod angles, positions, and arc lengths all factoring into the arc force control performance. *If you are new to using an inverter welder, there are some aspects that will seem different. One of the main ones is that the arc is better controlled in most situations by "pushing in" when the arc seems to get weak or unstable and the arc force will kick in as the voltage drops. If the arc length is too long, the voltage rise will signal the inverter to shut down and will terminate welding output. This is done to limit amp draw on the circuit.* This threshold is shorter than most transformers, and an extremely long arc cannot be maintained. However, with a little practice, the arc will be easy to manage with some adaptation in technique.
6. Strike the arc with either the tapping method or the match strike method. Beginners usually find that the match strike method typically yields the best results.



Component Identification and Explanation

Stick Welding Information

HELPFUL HINT:

Pay particular attention to the Arc Force setting as it affects the aggressiveness of the arc and the amp response. Set the Arc force to approximately 30-50% and readjust it from that point to find the optimum setting. Adjust in increments of 5% up or down from there to obtain the best results. Usually, an increase in the arc force for cellulose based flux welding rods is helpful. Lowering the Arc force setting is generally desirable for rods iron powder/Titania based flux. Too much arc force will create overheating of the welding rod, and even cause them to flame up. Too little can lead to sticking and arc snuffing. Use the Hot Start features to improve arc starting and cut down on failed arc strikes. Hot Start Amps refers to the % over the set amps that the amps will be boosted during arc striking until the arc is established. Hot Start Intensity controls the amount of time that the Hot Start stays engaged after the arc is struck. Start by setting Hot Start to somewhere between 30% and 50% and set hot start time to .5-1 seconds. Adjust in increments of 5% up or down to obtain best starting results.

When welding, the weld will be slower than MIG speed. One of the most common mistakes for users transitioning from MIG to Stick welding is the travel speed. Allow the metal to fill the puddle as the rod travels forward. Be sure to try to separate the difference between the slag and the molten pool of metal. The slag will coalesce behind the puddle if travel and rod angle is correct. Do not let the slag travel in front of the puddle. Keep the top of the rod inclined to the direction of travel around 10-20 degrees while welding in the flat position (Electrode holder should be in front and inline of the puddle). To begin, simply start the arc, and then drag the rod slowly and carefully along the metal, allowing the rod flux to provide a standoff between the metal filler and the puddle. Be sure to keep feeding the rod steadily downward into the puddle as the rod melts. In the case of E6010, 6011, and other rods with a cellulose based flux, a slight stepping motion in front of the puddle about 1/8"-1/4" in front of the puddle can be used as a key hole opens up in the weld joint, ahead of the puddle. This is also called "whipping" the rod. Do not flip the end of the rod away from the puddle in a arc motion or the arc may terminate while using E6010 or similar cellulosic rods. When experience is gained, numerous manipulation methods may be used with rods such as E7018, 7014, 6013, and 7024. Weave the rod no more than 2.5 times the width of the welding rod. To begin weaving, weave small, tight patterns similar to C's, cursive E's, V's, or even figure 8's.

Troubleshooting

Common MIG/Flux-Core Issues

NO.	Trouble	Possible Cause	Solution
1.	Unit is switched on, but the power light isn't on. Wire will not feed.	Switch damaged. Service Breaker/ Input Line Damaged Fuse	Check. Replace. Check. Replace.
2.	After welding machine is overheating and the fan does not work.	Fan damaged. Fan connector plus is loose	Replace. Check. Reinstall.
4.	Intermittent, wandering arc.	Work Clamp not connected directly to part being welded. Work Clamp worn/damaged Torch height too high.	Reconnect. Replace. Reduce MIG torch height to under 3/8" (for short circuit)
5.	Porosity of the Weld. Discolored weld color. Tungsten is discolored.	Low flow rate of shielding gas. High flow rate of shielding gas. Possible gas leaks internally or externally due to loose fittings. Base metal is contaminated with dirt or grease.	Increase flow rate on regulator. Check for kinks in tubing. Increase post-flow time. Reduce stick-out to less than 1/4". Increase gas nozzle size. Clean metal thoroughly with approved metal cleaner, or use acetone and a rag to clean metal.
6.	Weld quality is poor. Weld is dirty/oxidized, or porous.	Drafty conditions. The welder is located on the workpiece and is blowing gas off due to fan activity. Solenoid is sticking. For Flux Core, a certain amount of spatter, haze and smoke is common.	Eliminate drafts. Move welder. Check if there is sufficient shielding gas left in tank. Check gas flow. Adjust for higher flow of gas. Listen for audible click of gas solenoid. If no click is heard, then contact Everlast Support. Clean weld properly. Increase pre flow or post flow. Check polarity is correct for either MIG or Flux-Core, especially after changing between processes.
7.	Unstable Arc. Spatter.	Bad work clamp connection. Metal is indirectly connected through table or other item. Incorrect settings	Change Work Clamp. Use a direct connection to the part being welded. Check and adjust settings. Spatter usually increases when smaller wires are at the maximum welding capacity.
8.	Continuous Overheating	Settings too high. Too large of wire for job. Fan not running.	Reduce Settings, use smaller wire Check fan, repair or replace if not running or running at low speed. If it is not running correctly (fan should run continuously) contact Everlast.
9.	Other.		Contact Everlast.

Troubleshooting

WARNING SCREENS

IMPORTANT!

Occasionally a warning screen may pop up and interrupt welding. Pay attention to the code and follow the directions. In most cases it will explain the problem and cause. If the condition cannot be resolved, contact Everlast Tech Support for further help and diagnosis.

ERROR

04

Check manual for error code help. Contact Tech Support for further diagnosis.

Error	INDICATION	Possible Cause	Solution
01	OVERHEAT	Exceeded Duty Cycle	Allow to Rest and run at idle without welding for 15 minutes to cool. Do not shut off!
		Fan not running.	Check/Replace
		Dirty Internals	Check and Clean with dry compressed air.
2.	After welding machine is overheating and the fan does not work.	Fan damaged.	Replace.
		Fan connector plus is loose	Check. Reinstall.
4.	Intermittent, wandering arc.	Work Clamp not connected directly to part being welded.	Reconnect.
		Work Clamp worn/damaged	Replace.
		Torch height too high.	Reduce MIG torch height to under 3/8" (for short circuit)
5.	Porosity of the Weld. Discolored weld color. Tungsten is discolored.	Low flow rate of shielding gas. High flow rate of shielding gas. Possible gas leaks internally or externally due to loose fittings. Base metal is	Increase flow rate on regulator. Check for kinks in tubing. Increase post-flow time. Reduce stick-out to less than 1/4". Increase gas nozzle size. Clean metal thoroughly with approved metal cleaner, or use acetone and a rag to clean metal.
6.	Weld quality is poor. Weld is dirty/oxidized, or porous.	Drafty conditions. The welder is located on the workpiece and is blowing gas off due to fan activity. Solenoid is sticking.	Eliminate drafts. Move welder. Check if there is sufficient shielding gas left in tank. Check gas flow. Adjust for higher flow of gas. Listen for audible click of gas solenoid. If no click is heard, then contact Everlast Support. Clean weld properly. Increase pre flow or post flow.
		For Flux Core, a certain amount of	Check polarity is correct for either MIG or Flux-Core, especially after changing between processes.