



Installation Instructions

Kodlin 3-1 Rear Taillight Indicators K68461 / K68462 and K68463 / K68464

1. Securely lift up the motorcycle, turn the ignition off, disconnect the battery or remove the main fuse. For installation on Harley-Davidson models deactivate the alarm system or make sure that the key fob is close to the bike. Prior to disconnecting the electricity, the ignition needs to be turned on. Check your manual for details.
2. We recommend testing the functionality of the module prior to installation.
3. Attention: Connect to 12V DC power only (standard with motorcycles) to avoid the termination of any warranty claims!
4. Please only install at your motorcycle where it is very visible, and the view of light distribution is not blocked (with saddlebags or other accessories) to any vehicles behind you when riding. Do not install them close to inflammable areas (gas tank, fuel lines, etc.)
5. Prevent sharp bending of the cables and insulate the connections. We recommend adding additional protection with heat shrink tubes.
6. The flashing frequency can change when converting the original indicators on CAN-BUS models. The installation of a load equalizer will solve that problem
7. Install the 3-1 rear taillight indicators with the M8 nuts, spring washers and washers that are included in this kit.
8. Connect the battery or install the main fuse after installation and please check that your CAN-BUS and ABS system are functioning accurately. For HD models reverse the disconnecting procedure of step (1). Check your manual for details.

Cable Connection:

Black – Ground (-)

Red – Brake Light (+)

Yellow – Running Light (+)

Brown – Turn (+)

Note: It is the installer's responsibility to ensure that all the fasteners are tightened before operation of the motorcycle (we recommend following the ft lb torque specs). Kodlin will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required

Experience with soldering electric cables is necessary to install this product. We recommend working with a certified motorcycle shop.

Tip: If the installation of these indicators is done on the original fender struts of a Harley Davidson Softail, Dyna or Sportster model, we recommend the use of our Fender Struts Adapters part number K68483 or K68484

Attention! Before each use of the vehicle, check the functionality of the indicators and lights.