



# Champion Urn Vault Instructions

FOR VAULTS: VNO-370 & VNO-371

Prior to sealing, clean any dust off the surface of the urn vault—especially on edges where the adhesive will be applied.

A clean, dry surface ensures the best bond when sealing your urn vault.



## PARTS

Please check that you have the following parts:



URN VAULT BASE



URN VAULT LID



BOLTS AND WASHERS (4)



ADHESIVE



APPLIQUES (2) AND ENGRAVED PLATE



CREMATION URN  
(Not Included)



WRENCH OR 7/16" SOCKET  
(Not Included)

## INSTRUCTIONS

**NOTE:** If a brass plate was purchased, you may affix it to the inside or outside of the urn vault in a location of your choice.

- 1 Remove the 4 bolts and washers from the corners of the lid and set them aside.
- 2 Remove lid and place it upside down on a soft cloth.
- 3 Place filled cremation urn inside the base of the Champion Urn Vault.
- 4 Cut the tip off of the adhesive.
- 5 Apply a continuous line of adhesive around the entire inside edge of the vault lid where the flat edge with bolt holes meets the molded edge. (See image at right.)
- 6 Pick up and turn lid over so that adhesive is now facing down and place the vault lid on top of vault base.
- 7 Replace 4 washers and bolts in the corners and turn until secure.  
**Note:** Do not over-tighten or strip the bolts.
- 8 Peel the red tape to reveal adhesive strips on the lid. Position 2 appliques in the recessed areas and press firmly. Position the plate in the middle of the lid and press firmly.



Need more help?

Call us at (888) 872-0228

stardust  
memorials

[www.stardust-memorials.com](http://www.stardust-memorials.com)