REVISIONS			
LTR	DESCRIPTION	DATE	CHECKED
Ð	REVISED	9 - 10 - 90	IJS
С	REVISED	9 - 21 - 95	IJS
D	SEE SHEET 2	7 - 09 - 13	JG

INSTALLATION INSTRUCTIONS

- 1. PREPARE INACTIVE DOOR AS SHOWN IN FIGURE 1. (TOP CORNER SHOWN)
- 2. PREPARE FRAME FOR ANSI A115.4 STRIKE AS IN FIGURE 2. LOCATE STRIKE TO LINE UP WITH BOLT. INSTALL STRIKE.
- 3. INSTALL TRIMCO 3910 OR 3911 DUST PROOF STRIKE IN FLOOR. (TEMPLATE AVAILABLE) OR ANSI A116.4 STRIKE SHOWN IN FIGURE 2. LOCATE STRIKE TO LINE UP WITH BOLT. INSTALL STRIKE.
- 4. INSTALL TRIMCO 3810 AS SHOWN IN FIGURE 3.
- 5. HANG DOOR.
- 6. ADJUST BOLT TO PROVIDE 1/8" CLEARANCE BETWEEN BOLT AND STRIKE. TO ADJUST BOLT, REMOVE GUIDE. ROTATE BOLT END UP OR DOWN AS REQUIRED, THEN REPLACE GUIDE.
- 7 INSTALL TRIGGER STRIKE ON ACTIVE DOOR. TRIGGER STRIKE TO LINE UP WITH CENTERLINE OF TRIGGER AS SHOWN IN FIGURE 4. INSTALL STRIKE USING 2 #8 X 1" SMS. SHIM AS REQUIRED TO PROVIDE 3/32" CLEARANCE BETWEEN INACTIVE DOOR AND TRIGGER STRIKE



