



Top Of Door Mounting

**Frame Stop Mounting
(Push Side)**
Figure 1a




**Frame Surface Mounting
(Pull Side)**
Figure 1b



Bottom Of Door Mounting

Figure 2



Item	Description	Qty.
1	Retainer	2
2	Surface Bolt	1
3	Flat Mortise Strike	1
4	Angle Strike	1
5	Screw, 1/4-20 x 2-5/8"	4
6	Grommet Nut	4
7	Screw, 1/4-20 x 3/4"	3
8	Anchor	2

Note: Parts used depend on mounting application.

Attention Installer

Any retrofit or other field modification to a fire rated opening can potentially impact the fire rating of the opening, and Yale Locks & Hardware makes no representations or warranties concerning what such impact may be in any specific situation. When retrofitting any portion of an existing fire rated opening, or specifying and installing a new fire-rated opening, please consult with a code specialist or local code official (Authority Having Jurisdiction) to ensure compliance with all applicable codes and ratings.



Installation Instructions

Strike Mounting:

- Determine if bolt is to be mounted at top (Fig 1) or bottom (Fig 2) of door.
- A 2-3/4" backset is recommended.

Top of Door (Frame mounted strike, Fig 1a):

1. Locate strike on frame as shown and mark hole locations.
2. Drill and tap for 1/4-20 machine screws. (#8 drill and 1/4-20 tap are required.)
3. Secure strike with three 1/4-20 x 3/4" screws supplied.

Bottom Of Door (Floor mounted strike, Fig 2):

1. 1-1/8" dia x 1-1/2" deep hole is required in floor to accept surface bolt.
2. Mark and drill two, 7/16" dia. x 1-1/4" deep holes for strike anchors.
3. Secure the strike with two anchors and 1/4-20 x 3/4" screws supplied.

Surface Bolt Mounting (Fig 1b):

1. Slide the knob end retainer to the stop pin.
2. Locate surface bolt and retainers on door as shown and mark location of through-bolts.
3. Check bolt alignment in strike before drilling holes.
4. Drill four 9/32" dia. holes through door.
5. Open holes for grommet nuts on opposite side of door using "V" size drill.
6. Secure retainers to the door using grommet nuts and 1/4-20 x 2-5/8" screws supplied.
7. See template 7601-0010 for alternate mounting locations.

Yale Locks & Hardware

100 Yale Avenue, Lenoir City, TN 37771 • Product Support Tel 800.438.1951 • Fax 800.338.0965 • www.yalelocks.com

Yale Locks & Hardware is a division of Yale Security Inc., an ASSA ABLOY Group company.

Yale® is a registered trademark of Yale Security Inc., an ASSA ABLOY Group company. Other products' brand names may be trademarks or registered trademarks of their respective owners and are mentioned for reference purposes only. These materials are protected under U.S. copyright laws. All contents current at time of publication. Yale Security Inc. reserves the right to change availability of any item in this catalog, its design, construction, and/or its materials. Copyright © 2011, Yale Security Inc., an ASSA ABLOY Group company. All rights reserved. Reproduction in whole or in part without the express written permission of Yale Security Inc., an ASSA ABLOY Group company is prohibited.

YALE, with its unique global reach and range of products, is the world's favorite lock.

ASSA ABLOY is the global leader in door opening solutions, dedicated to satisfying end-user needs for security, safety and convenience.