

Designed by Jacques Adnet

PRODUCT



Item no.: 61070-XX
+ style code

DESCRIPTION

Few designers have succeeded in making a mirror a design icon but Jacques Adnet was the exception. Today, the elegant leather mirror that Adnet designed in 1950 provides inspiration for designers all over the world. His style is the epitome of luxury, so his 1950's collaboration with the exclusive French fashion house Hermès was a natural. In association with Hermès, Adnet developed a Collection of discreet yet voluptuous leather-covered furniture and interior accessories. This distinctive, round leather mirror with equestrian inspired detailing is a perfect example of Adnet's designs at that time. The mirror is available in either black, olive green or brown leather with strap and in three sizes: Ø45, Ø58 and Ø70 cm. The length of leather strap that supports the mirror is in direct proportion to the mirror diameter.

VERSION

- Tan Full Grain aniline leather / mirror glass
- Black Full Grain aniline leather / mirror glass
- Olive Full Grain aniline leather / mirror glass

MIRROR VERSION

Series contains the following:


Ø45, Ø58, Ø70



ACCESSORIES

Adnet hanging - Brass - Order item no.: 61000-99050

COLOURS



// Tan

// Black

// Olive

FACTS

MEASUREMENT

H:140 X Ø70 cm
Depth of mirror frame: 7 cm
Strap width: 2.3 cm
Leather thickness frame 4,5 X two layers: 9 mm
Leather thickness strap: 4,5 mm
Mirror glass 4mm according to EN 1036-2

WEIGHT ITEM

7,7 kg

PACKAGING TYPE

Cardboard box

PACKAGING MEASUREMENT - L X W X H CM

L:84 W:84 H:13,5 CM

WEIGHT PACKAGING - MATERIAL TYPE

- Delivery note: 10 g
- Certificate: 10 g
- Assembly instructions: 10 g
- Bubble postal bag: 10 g
- PE polybag: 5 g
- Mounting parts: 45 g
 - Bracket: Burnished brass
 - Drywall plug Driva TP12
 - Hanger bolt
 - Hexalobular socket key
 - Tack-It removable adhesive
 - Nylon dowel 8X40 mm
- Cardboard box outer packaging quality ---: 1544 g
- Cardboard box inner packaging quality ---: 1050 g
- Polystyrene EPS foam: 840 g

WEIGHT PACKAGING - TOTAL

11,5 kg

NUMPER OF PARCELS

1 pcs.

Designed by Jacques Adnet

CLEANING AND MAINTENANCE

For normal cleaning, vacuum or dust frequently with a clean, dry cloth. If leather is soiled, it can be wiped with a damp soft cloth and a lather of any mild soap and a minimum amount of lukewarm water. Do not spot clean leather; clean the entire surface. Wipe clean with a damp cloth and dry with a clean, soft cloth.

For spots and spills, wipe excess liquid immediately with a clean cloth or sponge; let the leather air dry. If further cleaning is necessary, sponge the entire surface with clean, lukewarm water. Let the leather air dry; never use a hair dryer or other heat source to dry leather.

For stubborn spots and stains, apply a mild, nonabrasive soap solution with a clean, wet sponge. Rinse well and let air dry. For butter, oil, or grease, wipe the leather with a clean, dry cloth and let the remainder of the oil dissipate into the leather. Do not apply water or try to wash a grease spot.

Do not use saddle soap, cleaning solvents, oils, furniture polishes, varnishes, abrasive cleaners, detergents, or ammonia on leather; they will ruin the finish, causing it to become sticky and cracked.

ENVIRONMENT

Parts can be separated and sorted for recycling.

INSTALLATION INSTRUCTIONS

56-15-300-02 Mounting instr. Adnet Circular Mirror.

DK

RENDSERINGS

For normal cleaning, vacuum or dust frequently with a clean, dry cloth. If leather is soiled, it can be wiped with a damp soft cloth and a lather of any mild soap and a minimum amount of lukewarm water. Do not spot clean leather; clean the entire surface. Wipe clean with a damp cloth and dry with a clean, soft cloth.

For spots and spills, wipe excess liquid immediately with a clean cloth or sponge; let the leather air dry. If further cleaning is necessary, sponge the entire surface with clean, lukewarm water. Let the leather air dry; never use a hair dryer or other heat source to dry leather.

For stubborn spots and stains, apply a mild, nonabrasive soap solution with a clean, wet sponge. Rinse well and let air dry. For butter, oil, or grease, wipe the leather with a clean, dry cloth and let the remainder of the oil dissipate into the leather. Do not apply water or try to wash a grease spot.

Do not use saddle soap, cleaning solvents, oils, furniture polishes, varnishes, abrasive cleaners, detergents, or ammonia on leather; they will ruin the finish, causing it to become sticky and cracked.

EN

CLEANING

For normal cleaning, vacuum or dust frequently with a clean, dry cloth. If leather is soiled, it can be wiped with a damp soft cloth and a lather of any mild soap and a minimum amount of lukewarm water. Do not spot clean leather; clean the entire surface. Wipe clean with a damp cloth and dry with a clean, soft cloth.

For spots and spills, wipe excess liquid immediately with a clean cloth or sponge; let the leather air dry. If further cleaning is necessary, sponge the entire surface with clean, lukewarm water. Let the leather air dry; never use a hair dryer or other heat source to dry leather.

For stubborn spots and stains, apply a mild, nonabrasive soap solution with a clean, wet sponge. Rinse well and let air dry. For butter, oil, or grease, wipe the leather with a clean, dry cloth and let the remainder of the oil dissipate into the leather. Do not apply water or try to wash a grease spot.

Do not use saddle soap, cleaning solvents, oils, furniture polishes, varnishes, abrasive cleaners, detergents, or ammonia on leather; they will ruin the finish, causing it to become sticky and cracked.

DE


REINIGUNG

Für normale Reinigung, saugen Sie häufig mit einem sauberen, trockenen Tuch ab. Wenn die Lederart verschmutzt ist, kann sie mit einem feuchten, weichen Tuch und einer geringen Menge milden Seifenlauge und lauwarmem Wasser abgewaschen werden. Verwenden Sie keine Flecklöser; reinigen Sie die gesamte Oberfläche. Wischen Sie mit einem feuchten Tuch ab und trocknen Sie mit einem sauberen, weichen Tuch ab.

Für Flecken und Verschüttungen, wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab; lassen Sie das Leder lufttrocknen. Wenn eine weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder lufttrocknen; verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Für hartnäckige Flecken und Verfärbungen, verwenden Sie eine milde, nicht-abrasive Seifenlösung mit einem sauberen, feuchten Schwamm. Spülen Sie gründlich ab und lassen Sie lufttrocknen. Für Butter, Öl oder Fett, wischen Sie das Leder mit einem sauberen, trockenen Tuch ab und lassen Sie den Rest des Öls in das Leder dissipieren. Verwenden Sie kein Wasser oder versuchen Sie, einen Fettfleck zu waschen.

Verwenden Sie keine Sattelseife, Reinigungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reiniger, Detergenzien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.



INDHOLD/CONTENTS/INHALT:


Ø1 x 1 x 1 x 1 x 1 x 1 x 1

1. DK: Monterings af holder.
EN: How to mount the bracket.
DE: Montage der Halterung.

DK: Trævæg.
EN: Wooden wall.
DE: Holzwand.

DK: Betonvæg.
EN: Concrete wall.
DE: Betonwand.

2. DK: Monterings af metal skive til magnet.
EN: How to mount the metal spacer for the magnet.
DE: Montage der Abstandhalter für den Magnet.




DK: Monter den nærtliggende metalplade på væggen 25 mm fra bunden af spejlet. Magnetens på bagsiden af spejlet vil dermed sikre, at det altid hænger fast ind til væggen.

EN: Mount the enclosed metal spacer on the wall 25 mm from the bottom of the mirror. The magnet on the back of the mirror will then ensure, that it always hangs close to the wall.

DE: Montieren Sie die beigefugte Metallscheibe in der Höhe von 25 mm vom unteren Rahmen des Spiegels an der Wand. Der Magnet auf der Rückseite des Spiegels will dadurch sichern, dass der Spiegel immer an der Wand hängt.

MINIMUM CEILING HEIGHT



Designed by Jacques Adnet

PRODUCT



COLOURS



DESCRIPTION

Few designers have succeeded in making a mirror a design icon but Jacques Adnet was the exception. Today, the elegant leather mirror that Adnet designed in 1950 provides inspiration for designers all over the world. His style is the epitome of luxury, so his 1950's collaboration with the exclusive French fashion house Hermès was a natural. In association with Hermès, Adnet developed a Collection of discreet yet voluptuous leather-covered furniture and interior accessories. This distinctive, round leather mirror with equestrian inspired detailing is a perfect example of Adnet's designs at that time. The mirror is available in either black, olive green or brown leather with strap and in three sizes: Ø45, Ø58 and Ø70 cm. The length of leather strap that supports the mirror is in direct proportion to the mirror diameter.

The mirror is also available three colors in Alcantara in Ø58 cm, Dusty cedar, Safari sand and Wild dove.


VERSION

- Tan Full Grain aniline leather / mirror glass
- Black Full Grain aniline leather / mirror glass
- Olive Full Grain aniline leather / mirror glass
- Wild dove Alcantara / mirror glass (only available in Ø58 cm)
- Dusty cedar Alcantara / mirror glass (only available in Ø58 cm)
- Safari sand Alcantara / mirror glass (only available in Ø58 cm)

MIRROR VERSION

Series contains the following:

Ø45, Ø58, Ø70



ACCESSORIES

Adnet hanging - Brass - Order item no.: 61000-99050

FACTS

MEASUREMENT

H: 116 X Ø58 cm
 Depth of mirror frame: 7 cm
 Strap width: 2.3 cm
 Leather / Alcantara thickness frame 4,5 X two layers: 9 mm
 Leather / Alcantara thickness strap: 4,5 mm
 Mirror glass 4mm according to EN 1036-2

WEIGHT ITEM

5,7 kg

PACKAGING TYPE

Cardboard box

PACKAGING MEASUREMENT - L X W X H CM

L:70 W:70 H:13,5 CM

WEIGHT PACKAGING - MATERIAL TYPE

- Delivery note: 10 g
- Certificate: 10 g
- Assembly instructions: 10 g
- Bubble postal bag: 10 g
- PE polybag: 5 g
- Mounting parts: 45 g
 - Bracket: Burnished brass
 - Drywall plug Driva TP12
 - Hanger bolt
 - Hexalobular socket key
 - Tack-it removable adhesive
 - Nylon dowel 8X40 mm
- Cardboard box outer packaging quality ---: 1150 g
- Cardboard box inner packaging quality ---: 809 g
- Polystyrene EPS foam: 450 g

WEIGHT PACKAGING - TOTAL

8,1 kg

NUMPER OF PARCELS

1 pcs.

Designed by Jacques Adnet
CLEANING AND MAINTENANCE

Leather:

For normal cleaning, vacuum or dust frequently with a clean, dry cloth. If leather is soiled, it can be wiped with a damp soft cloth and a lather of any mild soap and a minimum amount of lukewarm water. Do not spot clean leather; clean the entire surface. Wipe clean with a damp cloth and dry with a clean, soft cloth.

For spots and spills, wipe excess liquid immediately with a clean cloth or sponge; let the leather air dry. If further cleaning is necessary, sponge the entire surface with clean, lukewarm water. Let the leather air dry; never use a hair dryer or other heat source to dry leather.

For stubborn spots and stains, apply a mild, nonabrasive soap solution with a clean, wet sponge. Rinse well and let air dry. For butter, oil, or grease, wipe the leather with a clean, dry cloth and let the remainder of the oil dissipate into the leather. Do not apply water or try to wash a grease spot.

Do not use saddle soap, cleaning solvents, oils, furniture polishes, varnishes, abrasive cleaners, detergents, or ammonia on leather; they will ruin the finish, causing it to become sticky and cracked.

Alcantara:

For normal cleaning, dust frequently with a clean, dry cloth. If there are difficult spots or stains, use specified Alcantara cleaning products. If such products are not available use a sponge or soft cloth wung in clean water and run over the whole Alcantara surface. Please do not wet the surface excessively. Let it dry and do not use a hair dryer, steam machine or other heat source to dry the Alcantara. Afterwards the surface can be brushed with a soft brush.

ENVIRONMENT

Parts can be separated and sorted for recycling.

INSTALLATION INSTRUCTIONS

56-15-300-02 Mounting instr. Adnet Circular Mirror.

DK

REINIGUNG

Reinigen Sie das Spiegelglas häufig mit einem sauberen, trockenen Tuch. Wenn das Spiegelglas verschmutzt ist, können Sie es mit einem sauberen, feuchten Tuch und einer milden Seife sowie einer minimalen Menge lauwarmen Wassers abwischen. Wischen Sie das gesamte Spiegelglas ab. Wischen Sie es mit einem sauberen, feuchten Tuch ab und trocknen Sie es mit einem sauberen, trockenen Tuch ab. Verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Bei Flecken und Verschüttungen wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab. Lassen Sie das Leder an der Luft trocknen. Wenn weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder an der Luft trocknen. Verwenden Sie niemals Wasser oder versuchen Sie, einen Fettfleck zu waschen.

Verwenden Sie keine Sattelseife, Reinigungsmittel, Lösungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reinigungsmittel, Detergentien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.

REINIGUNG

Reinigen Sie das Spiegelglas häufig mit einem sauberen, trockenen Tuch. Wenn das Spiegelglas verschmutzt ist, können Sie es mit einem sauberen, feuchten Tuch und einer milden Seife sowie einer minimalen Menge lauwarmen Wassers abwischen. Wischen Sie das gesamte Spiegelglas ab. Wischen Sie es mit einem sauberen, feuchten Tuch ab und trocknen Sie es mit einem sauberen, trockenen Tuch ab. Verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Bei Flecken und Verschüttungen wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab. Lassen Sie das Leder an der Luft trocknen. Wenn weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder an der Luft trocknen. Verwenden Sie niemals Wasser oder versuchen Sie, einen Fettfleck zu waschen.


Verwenden Sie keine Sattelseife, Reinigungsmittel, Lösungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reinigungsmittel, Detergentien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.

REINIGUNG

Reinigen Sie das Spiegelglas häufig mit einem sauberen, trockenen Tuch. Wenn das Spiegelglas verschmutzt ist, können Sie es mit einem sauberen, feuchten Tuch und einer milden Seife sowie einer minimalen Menge lauwarmen Wassers abwischen. Wischen Sie das gesamte Spiegelglas ab. Wischen Sie es mit einem sauberen, feuchten Tuch ab und trocknen Sie es mit einem sauberen, trockenen Tuch ab. Verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Bei Flecken und Verschüttungen wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab. Lassen Sie das Leder an der Luft trocknen. Wenn weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder an der Luft trocknen. Verwenden Sie niemals Wasser oder versuchen Sie, einen Fettfleck zu waschen.


Verwenden Sie keine Sattelseife, Reinigungsmittel, Lösungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reinigungsmittel, Detergentien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.



MONTAGE- / ASSEMBLY- / INSTRUCTIONS MONTAGEANLEITUNG

for

ADNET CIRCULAIRE MIRROR



EN

CLEANING

Reinigen Sie das Spiegelglas häufig mit einem sauberen, trockenen Tuch. Wenn das Spiegelglas verschmutzt ist, können Sie es mit einem sauberen, feuchten Tuch und einer milden Seife sowie einer minimalen Menge lauwarmen Wassers abwischen. Wischen Sie das gesamte Spiegelglas ab. Wischen Sie es mit einem sauberen, feuchten Tuch ab und trocknen Sie es mit einem sauberen, trockenen Tuch ab. Verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Bei Flecken und Verschüttungen wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab. Lassen Sie das Leder an der Luft trocknen. Wenn weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder an der Luft trocknen. Verwenden Sie niemals Wasser oder versuchen Sie, einen Fettfleck zu waschen.

Verwenden Sie keine Sattelseife, Reinigungsmittel, Lösungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reinigungsmittel, Detergentien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.

REINIGUNG

Reinigen Sie das Spiegelglas häufig mit einem sauberen, trockenen Tuch. Wenn das Spiegelglas verschmutzt ist, können Sie es mit einem sauberen, feuchten Tuch und einer milden Seife sowie einer minimalen Menge lauwarmen Wassers abwischen. Wischen Sie das gesamte Spiegelglas ab. Wischen Sie es mit einem sauberen, feuchten Tuch ab und trocknen Sie es mit einem sauberen, trockenen Tuch ab. Verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Bei Flecken und Verschüttungen wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab. Lassen Sie das Leder an der Luft trocknen. Wenn weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder an der Luft trocknen. Verwenden Sie niemals Wasser oder versuchen Sie, einen Fettfleck zu waschen.

Verwenden Sie keine Sattelseife, Reinigungsmittel, Lösungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reinigungsmittel, Detergentien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.

DE

REINIGUNG

Reinigen Sie das Spiegelglas häufig mit einem sauberen, trockenen Tuch. Wenn das Spiegelglas verschmutzt ist, können Sie es mit einem sauberen, feuchten Tuch und einer milden Seife sowie einer minimalen Menge lauwarmen Wassers abwischen. Wischen Sie das gesamte Spiegelglas ab. Wischen Sie es mit einem sauberen, feuchten Tuch ab und trocknen Sie es mit einem sauberen, trockenen Tuch ab. Verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Bei Flecken und Verschüttungen wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab. Lassen Sie das Leder an der Luft trocknen. Wenn weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder an der Luft trocknen. Verwenden Sie niemals Wasser oder versuchen Sie, einen Fettfleck zu waschen.

Verwenden Sie keine Sattelseife, Reinigungsmittel, Lösungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reinigungsmittel, Detergentien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.

REINIGUNG

Reinigen Sie das Spiegelglas häufig mit einem sauberen, trockenen Tuch. Wenn das Spiegelglas verschmutzt ist, können Sie es mit einem sauberen, feuchten Tuch und einer milden Seife sowie einer minimalen Menge lauwarmen Wassers abwischen. Wischen Sie das gesamte Spiegelglas ab. Wischen Sie es mit einem sauberen, feuchten Tuch ab und trocknen Sie es mit einem sauberen, trockenen Tuch ab. Verwenden Sie niemals einen Haartrockner oder andere Wärmequelle zum Trocknen des Leders.

Bei Flecken und Verschüttungen wischen Sie überschüssige Flüssigkeit sofort mit einem sauberen Tuch oder Schwamm ab. Lassen Sie das Leder an der Luft trocknen. Wenn weitere Reinigung erforderlich ist, wischen Sie die gesamte Oberfläche mit sauberem, lauwarmem Wasser ab. Lassen Sie das Leder an der Luft trocknen. Verwenden Sie niemals Wasser oder versuchen Sie, einen Fettfleck zu waschen.

Verwenden Sie keine Sattelseife, Reinigungsmittel, Lösungsmittel, Öle, Möbelpoliermittel, Lacke, Schleifmittel, abrasive Reinigungsmittel, Detergentien oder Ammoniak auf Leder; diese zerstören das Finish und machen es klebrig und spröde.


56-15-300-02


GUBI

MONTAGEANLEITUNG
 ASSEMBLY INSTRUCTIONS
 MONTAGEANLEITUNG

ADNET CIRCULAIRE

INHALTSVERZEICHNIS/INHALT





MAGNET

METAL SPACER

WALL

25 mm

2. DK: Montierung of metal sleeve to magnet.

EN: How to mount the metal spacer for the magnet.

DE: Montage der Abstandhalter für den Magnet.

1. DK: Montierung of holder.


EN: How to mount the bracket.

DE: Montage der Halterung.

DK: Trævæg

EN: Wooden wall

DE: Holzwand




04mm

DK: Betonvæg

EN: Concrete wall

DE: Betonwand



Min. 40 mm


03mm

DK: Montieren den montagering metal sleeve på bagveden af spejlet til derved sidst, så det altid hænger tæt ind til væggen.

EN: Mount the enclosed metal spacer on the wall 25 mm from the bottom of the mirror. The magnet on the back of the mirror will then ensure, that it always hangs close to the wall.

DE: Montieren Sie die beigelegte Metallschleife in der Höhe von 2,5 cm vom unteren Rahmen des Spiegels an der Wand. Der Magnet auf der Rückseite des Spiegels wird dadurch sichern, dass der Spiegel immer an der Wand hängt.

MINIMUM CEILING HEIGHT



Designed by Jacques Adnet

PRODUCT



Item no.: 61045-XX
+ style code

DESCRIPTION

Few designers have succeeded in making a mirror a design icon but Jacques Adnet was the exception. Today, the elegant leather mirror that Adnet designed in 1950 provides inspiration for designers all over the world. His style is the epitome of luxury, so his 1950's collaboration with the exclusive French fashion house Hermès was a natural. In association with Hermès, Adnet developed a Collection of discreet yet voluptuous leather-covered furniture and interior accessories. This distinctive, round leather mirror with equestrian inspired detailing is a perfect example of Adnet's designs at that time. The mirror is available in either black, olive green or brown leather with strap and in three sizes: Ø45, Ø58 and Ø70 cm. The length of leather strap that supports the mirror is in direct proportion to the mirror diameter.

VERSION

- Tan Full Grain aniline leather / mirror glass
- Black Full Grain aniline leather / mirror glass
- Olive Full Grain aniline leather / mirror glass

MIRROR VERSION

Series contains the following:

Ø45, Ø58, Ø70



ACCESSORIES

Adnet hanging - Brass - Order item no.: 61000-99050

COLOURS



FACTS

MEASUREMENT

H: 90 X Ø45 cm
Depth of mirror frame: 7 cm
Strap width: 2.3 cm
Leather thickness frame 4,5 x two layers: 9 mm
Leather thickness strap: 4,5 mm
Mirror glass 4mm according to EN 1036-2

WEIGHT ITEM

3,9 kg

PACKAGING TYPE

Cardboard box

PACKAGING MEASUREMENT - L X W X H CM

L:60 W:60 H:13,5 CM

WEIGHT PACKAGING - MATERIAL TYPE

- Delivery note: 10 g
- Certificate: 10 g
- Assembly instructions: 10 g
- Bubble postal bag: 10 g
- PE polybag: 5 g
- Mounting parts: 45 g
 - Bracket: Burnished brass
 - Drywall plug Driva TP12
 - Hanger bolt
 - Hexalobular socket key
 - Tack-It removable adhesive
 - Nylon dowel 8X40 mm
- Cardboard box outer packaging quality ----: 940 g
- Cardboard box inner packaging quality ----: 710 g
- Polystyrene EPS foam: 450 g

WEIGHT PACKAGING - TOTAL

6 kg

NUMBER OF PARCELS

1 pcs.

ADNET CIRCULAIRE SMALL // GLASS MIRROR

ADNET COLLECTION

Designed by Jacques Adnet CLEANING AND MAINTENANCE

For normal cleaning, vacuum or dust frequently with a clean, dry cloth. If leather is soiled, it can be wiped with a damp soft cloth and a lather of any mild soap and a minimum amount of lukewarm water. Do not spot clean leather; clean the entire surface. Wipe clean with a damp cloth and dry with a clean, soft cloth. For spots and spills, wipe excess liquid immediately with a clean cloth or sponge; let the leather air dry. If further cleaning is necessary, sponge the entire surface with clean, lukewarm water. Let the leather air dry; never use a hair dryer or other heat source to dry leather. For stubborn spots and stains, apply a mild, nonabrasive soap solution with a clean, wet sponge. Rinse well and let air dry. For butter, oil, or grease, wipe the leather with a clean, dry cloth and let the remainder of the oil dissipate into the leather. Do not apply water or try to wash a grease spot. Do not use saddle soap, cleaning solvents, oils, furniture polishes, varnishes, abrasive cleaners, detergents, or ammonia on leather; they will ruin the finish, causing it to become sticky and cracked.

ENVIRONMENT

Parts can be separated and sorted for recycling.

INSTALLATION INSTRUCTIONS

56-15-300-02 Mounting instr. Adnet Circular Mirror.

MINIMUM CEILING HEIGHT

