

ASSEMBLY INSTRUCTIONS

BIG-GUN™ Piggy Back Regulator







STEP 1:Remove the set screws from both the main regulator and the pilot regulator.



STEP 2: Place the O-Rings from the piggy back kit in the main regulator as shown.



Insert the bolts supplied in the piggy back kit into the pilot regulator. Align pilot regulator with the main regulator so that the alignment pins and bolts match up.



STEP 4:Complete the assembly by tightening the bolts joining the pilot and main regulator.