



# MYLAR DISPENSER INSTALLATION INSTRUCTIONS



**WARNING:** Wear safety goggles and gloves. Metal shavings will be produced during these installation procedures. It is also recommended a drop cloth or plastic sheeting be used to catch metal shavings and protect the equipment during installation.

**NOTE:** Installation of a mylar dispenser requires a window frame kit to be installed.



## 1. INSTALLATION OF MYLAR ROLL HOLDER

- Position the roll holder parallel to and on the right of the window kit with the screw holes to the outside. If the right side of the window is obstructed, the roll holder can be installed on the left side of the window.
- Position the roll holder vertically so the bottom of the mylar roll will line up with the bottom of the glass and attach with the two self-tapping screws provided.



## 2. INSERT MYLAR ROLL

- Unscrew the window frame wing nuts and remove the outer frame.
- Slide the mylar roll into the roll holder.
- Unroll the mylar roll and feed it behind the glass until it reaches 2-3" beyond the edge of the glass.



## 3. REASSEMBLE THE WINDOW FRAME

- Replace the outer window frame and screw the wing nuts back in place.

### PART NUMBERS

011190 - Mylar Dispenser Kit

011191 - Mylar 12-1/2" x 10' roll

**WHEN THE MYLAR NEEDS TO BE REPLACED, TURN OFF THE BLOWER, LOOSEN THE WING NUTS, PULL NEW MYLAR IN FRONT OF THE GLASS AND CUT THE EXCESS OFF.**



**800-800-0665    WWW.IDSBLAST.COM**

**2717 Tobey Drive • Indianapolis, IN 46219**