



CUSTOM GRILLES INSTALLATION INSTRUCTIONS

TOOLS REQUIRED FOR INSTALLATION: Flat head screwdriver.

To begin installation, open your vehicles hood as you will be working from the inside. There are two ways to remove your original grilles: By depressing the tabs with your fingers or by separating the front and rear of the grille with a flat head screw driver. Read through both installation processes before proceeding to help choose the best method suited for you.

1) Depressing Tabs:

Locate the 6 tabs along the perimeter of the grille . They are black in color and are part of the rear section of the grille and have a flat spot for your finger to press on. To remove the grille in one piece these 6 tabs must be depressed with your fingers to allow the grille to pop out through the front. This may require more than one hand, as the tabs are very firmly set.



2) Grille Separation:

Separating the grilles is proven to be the easier method of grille removal, although it will take more care to ensure no clips are damaged in the removal process. Locate the 6 chrome tabs along the perimeter of the grille (A). These are part of the front section of the grille, you will be removing the rear portion first. While pulling slightly on the inside portion of the grille, (this is only to keep the clips apart as you begin to separate them individually) using your flat head screwdriver gently lift the chrome tabs one by one to release them. Remember to only lift them high enough to separate, anything more may cause them to break. Once they are all released the front and rear sections of the grille will com apart.



INSERTING GRILLES:

Line up the grille and push in while distributing equal force along the grille with you hands. They should simply snap into place. Failing to insert with equal force may result in too much pressure on one clip, causing it to break.

