



DON'T FORGET

These instructions can be found in color and expandable at QA1.net

Technical Support Line: (952) 985-5675 Email: sales@QA1.net

INSTALLATION INSTRUCTIONS

88-98 C1500 FRONT SWAY BAR

P/N 52867

TOOLS AND SUPPLIES REQUIRED

- Floor Jack
- Jack Stands
- SAE Wrench Set
- Ratchet & SAE Socket Set

PRE-INSTALLATION NOTES:

This sway bar was not designed to work with the factory lower control arms.

INSTALLATION:

1. Mount the sway bar to the original sway bar frame mounts using the provided bushings, bushing locator tabs, and 3/8" hardware. Center the sway to the frame and torque to 30 lb. ft. **(Figure 1)**
2. Install the 1/2" right hand thread jam nuts onto right hand thread rod ends (#10) and thread into the anodized red adjustment sleeve (#8). Do the same on the left hand thread side of the adjuster sleeve with left hand thread jam nut on left hand thread rod end. Thread rod ends all the way into the adjustment sleeve. **(Figure 2)**




Figure 1





Figure 2

3. Attach the sway bar to the adjuster link using the specialty high misalignment stud (#3) with 1/2" washer and nylock nut on the sway bar side. The end link should be attached outboard of the sway bar on each side. **(Figure 3)** Attach the link side using high misalignment spacer (#6) and a 3/8" nylock nut. Torque connection to 31 lb. ft.
4. Install two stepped spacers (#13) into the rod end on the control arm side of the linkage and install onto the lower control arm using 3/8" x 2" bolt, two washers (outside of the tabs), and nylock nut.



Figure 3

BALLOON #	DESCRIPTION	QTY.
1	SWAY BAR, FRONT 1 3/8", BLACK	1
2	BUSHING, SWAY BAR FRAME MOUNT 1-1/4"	2
3	HIGH MISALIGNMENT STUD	2
4	WASHER, FLAT 1/2" SAE	2
5	NUT, NYLOCK JAM 1/2-20	2
6	HIGH MISALIGNMENT SPACER, .5" OD	2
7	NUT, NYLOCK 3/8-16	4
8	SLEEVE, .875" HEX ALUMINUM ANODIZED	2
9	2-PIECE ROD END	2
10	ROD END (C) 2-PC CARBON	2
11	JAM NUT, STEEL 1/2-20 RH	2
12	JAM NUT, STEEL 1/2-20 LH	2
13	SPACER, STEPPED 1/2" OD X .125"	4
14	BOLT, HEX 3/8-16 X 2"	2
15	WASHER, FLAT 3/8" SAE	4



READ ALL INSTRUCTIONS CAREFULLY AND THOROUGHLY PRIOR TO STARTING INSTALLATION. PRODUCTS THAT HAVE BEEN INSTALLED ARE NOT ELIGIBLE FOR RETURN. USE THE PROPER JACKING LOCATIONS. DEATH OR SERIOUS INJURY CAN RESULT IF INSTRUCTIONS ARE NOT CORRECTLY FOLLOWED. A GOOD CHASSIS MANUAL, AVAILABLE AT YOUR LOCAL PARTS STORE, MAY ALSO AID IN YOUR INSTALLATION.

• **DISCLAIMER / WARRANTY** •

QA1 WARRANTS THAT THE PRODUCTS WILL BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP FOR ONE YEAR FROM DATE OF SALE TO THE ORIGINAL PURCHASER. QA1 MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. QA1 SHALL HAVE NO OBLIGATION UNDER THE FOREGOING WARRANTY WHERE THE DEFECT IS THE RESULT OF IMPROPER OR ABNORMAL USE, YOUR NEGLIGENCE, VEHICLE ACCIDENT, IMPROPER OR INCORRECT INSTALLATION OR MAINTENANCE, NOR WHEN THE PRODUCT HAS BEEN REPAIRED OR ALTERED IN ANY WAY. QA1'S LIABILITY IN THE CASE OF DEFECTIVE PRODUCTS SUBJECT TO THE FOREGOING WARRANTY SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT, AT QA1'S OPTION, OF THE DEFECTIVE PRODUCTS.

THE USER UNDERSTANDS AND RECOGNIZES THAT RACING PARTS, SPECIALIZED STREET ROD EQUIPMENT, AND ALL PARTS AND SERVICES SOLD BY QA1 ARE EXPOSED TO MANY AND VARIED CONDITIONS DUE TO THE MANNER IN WHICH THEY ARE INSTALLED AND USED. QA1 SHALL BEAR NO LIABILITY FOR ANY LOSS, DAMAGE OR INJURY, EITHER TO A PERSON OR TO PROPERTY, RESULTING FROM THE INSTALLATION, DIRECT OR INDIRECT USE OF ANY QA1 PRODUCTS OR INABILITY BY THE BUYER TO DETERMINE PROPER USE OR APPLICATION OF QA1 PRODUCTS. WITH THE EXCEPTION OF THE LIMITED LIABILITY WARRANTY SET FORTH ABOVE, QA1 SHALL NOT BE LIABLE FOR ANY CLAIMS, DEMANDS, INJURIES, DAMAGES, ACTIONS, OR CAUSES OF ACTION WHATSOEVER TO BUYER ARISING OUT OF OR CONNECTED WITH THE USE OF ANY QA1 PRODUCTS. MOTORSPORTS ARE DANGEROUS; AS SUCH, NO WARRANTY OR REPRESENTATION IS MADE AS TO THE PRODUCT'S ABILITY TO PROTECT THE USER FROM INJURY OR DEATH. THE USER ASSUMES THAT RISK!