

Canopy Sneeze Guard Installation Guide Steps

INCLUDES:



4 THUMBScrews



4 SCREWS

4 SCREW CAPS




RIGHT SIDE*



4 WASHERS



BRACE PANEL*



GLASS PANEL*

**Image shown may vary slightly from equipment, depending on grill that your sneeze guard is intended to fit.*

ASSEMBLY

1. Open and Identify all parts and pieces. (Photo Step 1)
2. Remove existing nut and washer from top glass piece. Save these pieces for use in Step 5. (Photo Step 2)
3. Remove existing black screw and discard. Recommended: remove ONLY the two screws, one side at a time, so that the glass piece remains in place. (Photo Step 3)
4. Slide LEFT acrylic side panel under glass top and align the holes. (Photo Step 4)
5. Place new screws (3/4") into open holes. Use existing nut and washer (from Step 2) and screw back on. (Photo Step 5)
6. Repeat this step for the RIGHT acrylic side. (Photo: none)



STEP 1



STEP 2



STEP 3



STEP 5



STEP 4



OPTIONAL BACK PANEL:

1. Attach back panel by placing open holes in acrylic over bottom studs. Secure in place with thumb screws. (See photos 7A & 7B)



7A



7B