

Universal Canopy Sneeze Guard Grill Mount

INCLUDES:



*Image shown may vary slightly from image shown, depending on grill that your sneeze guard is intended to fit.

ASSEMBLY

1. With lip at bottom and facing front, align the brace panel with the 2 top-most screws of either side panel; use the 4 thumbscrews to attach, but do not over tighten.
2. Set assembly of both sides and brace panel onto roller grill.[†] With the correct distance of the sides achieved, tighten thumbscrews completely.
3. CAREFULLY position glass panel onto upper portion of sides in order to achieve the "canopy." **NOTE:** there is a front and back, you may need to rotate the glass to align the holes in the Glass Panel with the holes in the upper brace of the Side pieces.
4. Hold glass in place as you add a washer to a screw; insert from the top into one of the four holes. Loosely tighten a screw cap onto it from the bottom of the canopy to hold it in position.
5. Repeat for remaining three holes.
6. Tighten all screw caps, hold the screw from the top to ensure you achieve a tight fit.
7. Clean the glass (with a soft cloth), and you're done.

[†]You'll want to install accessories such as the FlavorRail ID bars or a Divider Kit on your roller grill and then set the Grill Mount Universal Canopy Sneeze Guard on the grill after. The Sneeze Guard can be lifted off after assembly to add grill accessories, but handle it carefully when moving.

NOTE: If you have a food**pros** 8033 or 8055 grill, your left and right side panels will include 2 set-screws per side that have been threaded into them already; tighten these against the sides of the grill.

