

## READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

911/912/930

Note: These door stay reinforcements are designed for use with the later door stays that have integrated nuts. Early door stays have integrated studs that are too short, so stays require modification to use this kit.

- 1.) If you have removable door speakers, install can be done by removing the speaker and working through the speaker hole. If you do not have door speakers, the first step will be to remove the door cards.
- 2.) Remove the door stay pin. Note: Once Pin has been removed, use care to ensure that the door does not swing open too far.
- 3.) Working on the hinge end of the door, loosen the two screws that hold the door stay in place. Reach inside the door to catch the door stay as you remove the screws.
- 4.) If the door stay area of the door has been bent or ripped, now is the time to repair it.
- 5.) Using the supplied grease, lubricate the door stay while it's out of the car.
- 6.) Reinstall door stay along with your new door stay reinforcement as shown in the diagram below.
- 7.) Reinstall door stay pin and speaker and/or door card.

