

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.



NOTE: This is a universal tow hook. Some applications may require additional hardware or brackets that are not included with this kit.

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

Parts List

- (4) Hex Head Cap Screws - 7/16-14 X1" - MC92865A669
- (4) Hex Nut - 7/16-14 - MC95462A032
- (4) Lock Washer- MC91102A765
- (1) Tow Hook
- (2) L Brackets

Race Tow Hook - Universal