



Order Online: WWW.RENNLINE.COM
EM Sales@rennline.com
PH 802.655.5311
FX 802-655-6283

Driven to improve excellence.

Retractable Tow Hook Assembly

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

These tow hook have been designed to be used on both sides of the car and can be mounted vertically or horizontally. Make sure that you have all parts required before installation. If you are missing anything, please call us immediately.



Parts List:

- (1) Tow hook assembly
 - (1) M12X40mmx1.75 Zinc Pltd Cap Screw MC 98164A304
 - (1) M12 Washer MC 91455A150
- (2) Tow stickers



Mount the tow hook assembly into the factory bumper shock location using the factory shock clamp and hardware on all 1974-89 Porsche 911/912/930. If this assembly is being used for a custom application, other brackets and fabrication may be required. NOTE: Not all fiberglass bumpers are the same depth. Therefore, shimming may be required at the back mounting bolt to achieve the desired amount of hook protruding through the bumper.



Cut a slot into bumper allowing tow hook to be extracted without rubbing on tow hook finish.