

Side Scoop Wire Mesh Grille Kit

991.1/991.2 Turbo/Turbo S

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.

(1) Right Side Scoop Grill
(1) Left Side Scoop Grill



1. Remove the air inlet trim piece from the quarter panel.
2. Place grilles over the vent housings.
3. If required, manipulate the grilles so that they fit precisely over the vent housings.
4. Reinstall the air inlet trim piece.