

Remote Pull Cable - T Handle

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

These are universal pull handles that can be used in many application. See below for installation.

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.

- (1) Pull Cable Assembly
- (1) Trim Ring (Power Off) EL21_trim_ring
- (1) Fender Washer
- (1) Nut
- (1) Barrel Nut NCW SM809
- (2) Stop Nuts MC90710A038
- (1) Cable Stop MFGS 4-219-MB

