

Kill Switch Mount

1965-98 911

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

Check to make sure you have all parts listed prior to installation.
If anything is missing contact us immediately.

(1) Kill Switch Mount



1. If you are installing this unit into a 1965-98 911, remove (2) consecutive fender bolts on the drivers side of the car and install bracket using the factory bolts.
2. Install switch and remote pulls. Note: these items are not included with this bracket, refer to there installation instructions for mounting.