

Aluminum Guage Bezels

911/912/964/993 1965-98

Check to make sure that you have all of the parts listed prior to installation. If anything is missing contact us immediately.

Parts List

- (5) Aluminum guage bezels
- (1) Sheet of Acrylic double sided adhesive



Cut the supplied tape into approximately 1/2" X 1/4" rectangles. Apply tape to the inside of each bezel as shown above.



Thoroughly clean factory bezels removing any contaminants such as Armor All that may inhibit the tape to properly adhere to the surface. Remove the backing from the applied tape and install the aluminum bezels over the top of the factory bezels. To insure proper adhesion of the tape, apply equal pressure to all sides of the bezels. Note: This is an acrylic based tape, full adhesion will not be achieved for a few days after installation.

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying conditions, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.