

Flat (non-hubcentric)

LS10.3F	LS10.5F	LS10.7F	LS10.7F	LS10.10F	LS10.12F
911 (1965-1975)	911 (1965-1975) F	911 (1965-1975) F	911 (1965-1975) F	911 (1965-1975) F	911 (1965-1975) F
930 (1975-1989)	930 (1975-1989) F	930 (1975-1989) F	930 (1975-1989) F	930 (1975-1989) F	930 (1975-1989) F
964 (1990-1994)	964 (1990-1994) C4	964 (1990-1994) C4	964 (1990-1994) C4	964 (1990-1994) C4	964 (1990-1994) C4

Hubcentric Spacers

LS10.5	LS10.7	LS10.10	LS10.12	LS10.15	LS10.18	LS10.20	LS10.30
911 (1965-1975) R	911 (1965-1975) R	911 (1965-1975) R	911 (1965-1975) R	911 (1965-1975) R	911 (1965-1975) R	911 (1965-1975) R	911 (1965-1975) R
930 (1975-1989) R	930 (1975-1989) R	930 (1975-1989) R	930 (1975-1989) R	930 (1975-1989) R	930 (1975-1989) R	930 (1975-1989) R	930 (1975-1989) R
944 (1982-1991)	944 (1982-1991)	944 (1982-1991)	944 (1982-1991)	944 (1982-1991)	944 (1982-1991)	944 (1982-1991)	944 (1982-1991)
964 (1990-1994)	964 (1990-1994)	964 (1990-1994)	964 (1990-1994)	964 (1990-1994)	964 (1990-1994)	964 (1990-1994)	964 (1990-1994)
993 (1994-1998)	993 (1994-1998)	993 (1994-1998)	993 (1994-1998)	993 (1994-1998)	993 (1994-1998)	993 (1994-1998)	993 (1994-1998)
996 (1998-2005)	996 (1998-2005)	996 (1998-2005)	996 (1998-2005)	996 (1998-2005)	996 (1998-2005)	996 (1998-2005)	996 (1998-2005)
997 (2005-2012)	997 (2005-2012)	997 (2005-2012)	997 (2005-2012)	997 (2005-2012)	997 (2005-2012)	997 (2005-2012)	997 (2005-2012)
991 (2012-2019)	991 (2012-2019)	991 (2012-2019)	991 (2012-2019)	991 (2012-2019)	991 (2012-2019)	991 (2012-2019)	991 (2012-2019)
CAYENNE	CAYENNE	CAYENNE	CAYENNE	CAYENNE	CAYENNE	CAYENNE	CAYENNE
PANAMERA	PANAMERA	PANAMERA	PANAMERA	PANAMERA	PANAMERA	PANAMERA	PANAMERA
CAYMAN/BOXSTER	CAYMAN/BOXSTER	CAYMAN/BOXSTER	CAYMAN/BOXSTER	CAYMAN/BOXSTER	CAYMAN/BOXSTER	CAYMAN/BOXSTER	CAYMAN/BOXSTER
				MACAN	MACAN	MACAN	MACAN
TAYCAN	TAYCAN	TAYCAN	TAYCAN	TAYCAN	TAYCAN	TAYCAN	TAYCAN

F = Front

R = Rear

C4 models require "Flat" spacers on front only