

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and

**Solid Motor Mounts**

**964/993/996/997**

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

Installation of long bolt hardware should be as follows.  
Long bolt, 1/2" washer, mount, machined washer, car, 1/2" washer, nut.

Note: If you are using the machined hex washers under the mount, it is necessary to chase a 3/32 drill through the mount weep hole to make the mount self draining.

- Parts List:
- (4) MS M8X45mm SS Button Head
  - (2) MS M12 Nylock Nut
  - (2) MS M12x95mm Screw
  - (2) MS M12x65mm Screw
  - (4) M8 Washer MC93475A270
  - (4) 1/2"x1.06" washer MC90126A033
  - (2) M08\_washer - machined washer

