

## READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

### Cayenne Dead Pedal (Tape Installation)

Note: your dead pedal may look different then the one used in these instruction. Rennline offers 3 different pedal designs for this automobile, but installation it the same for all.



1. Clean the factory vinyl pad using a cleaner that will remove any grease or contaminants that may effect the performance of the supplied tape.
- 2) Remove the protective coating on the tape. Slide the left edge of the dead pedal under the kick panel edge. Press dead pedal firmly against vinyl pad to help secure tape.
- 3). Enjoy your new Rennline Product.