

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

Parts List:

- (2) 6-32 x 3/16 Set Screw - MC 92311A143
- (1) 1/16" Hex Key - MC 7122A14
- (1) M5 SS Acorn Nut - MC94000A037
- (1) M5x25mm SS Hex Socket Screw - MC91292A129



To install, Simply remove the tow loop from your Rennline Tow hook. Slide the GoPro mount onto the screw as shown in Photo 1 and tighten the supplied set screws using the supplied hex key. Next, reinstall the tow loop using the instructions included in the tow hook kit. Lastly mount the GoPro to the Rennline GoPro mount making sure to tighten the GoPro thumb screw tight enough.

NOTE: Depending on the vehicle and the angle of the Tow hook , the GoPro may be pointing slightly off from center. Because of the wide angle of these cameras, this is not a concern.