

### READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

**Part List:**

(1) Mounting Bracket - P/N - PM16 or PM21

(1) P/N - PM01

- Aluminum Ball

- Magnetic Pad Assembly

- Steel pads

(1) Thread-Locking Alloy Button Head Socket Cap Screw - 10/32 x .5" - MC92360A248

\*\*Photos shown are for a MK7 (PM01.16), but install process for MK7.5 PM01.21) is the same.

1. Install the aluminum ball onto the metal bracket as shown using the supplied screw.

2. Pry the trim panel located below the radio/vent trim with a plastic trim removal tool. ( Photo 1)

3. Again, using the plastic trim removal tool, pry up the bottom half of the radio vent trim (Photo 2)

4. Remove the backing of the double sided tape and install the phone mount on the back side of the trim panel.

It will only align in one position as its cut to clear the extrusions on the back side of the trim panel. (Photo 3)

5. Reinstall all the plastic trim in reverse order of disassembly. (Photo 5)

6. Attach the phone to your mount.

7. Enjoy your new Rennline product.



Photo 1



Photo 2



Photo 3



Photo 4

