



Driven to improve excellence.

Order Online: [WWW.RENNLINE.COM](http://WWW.RENNLINE.COM)

EM Sales@rennline.com

PH 802.893.7311

FX 802-893-7366

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and

**Airbag Delete Cover**

964/993 All

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

Parts List     Airbag delete cover

**Step 1:** Remove the lower dash.

**Step 2:** Remove the factory airbag cover by removing the 3 lower phillips head screws and 4 upper allen head screws as indicated in photo 1.

**Step 3:** Install the Rennline cover and attach using factory hardware as shown in photo 2.

**NOTE:** Air bag **MUST** be removed prior to installing this cover.

**Step 4:** If using a lower dash pad or a Rennline lower dash delete panel. Install at this time. See photo 3 with Rennline lower dash delete panel installed.

