



Driven to improve excellence.

Order Online: WWW.RENNLINE.COM

EM Sales@rennline.com

PH 802.893.7311

FX 802-893-7366

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and

Aluminum Lock Pins

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

Parts List: (2) lock Pins
(6) rubber orings (installed) P/N - MC9262K121

Unscrew the factory pins and screw on the Rennline units as shown in photo 1.

Note: If the threaded shaft falls to the side after you remove the factory unit, it may be necessary to remove the top door padding. To do so, remove the cap and screw as shown in photo 2. Unscrew the front screw on 65-89 cars as shown in photo 3. 89-98 cars have 2 screws under the front cover as shown in photo 4.

Photo 1



Photo 2



Photo 3



Photo 4

