



Driven to improve excellence.

Order Online: WWW.RENNLINE.COM

EM Sales@rennline.com

PH 802.893.7311

FX 802-893-7366

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Do to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and

E-brake Handle

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.

Parts List: (1) E-brake handle
(1) Button
(2) M5x8mm set screw - MC91390A119
(1) Boot Bezel

Step 1 - If your car does not have an integrated E-brake handle boot, skip to step 2. Using a razor blade, cut all the way around the factory seam as shown in photo 1

Step 2 - Un-thread button and pull leather handle off E-brake housing as shown in photo 2.

Step 3 - Install boot bezel (only cars with integrated boot) and thread on aluminum button as shown in photo 3.

Step 4 - Install aluminum handle, rotate handle so set screws are pointing down. Tighten set screws.

Photo 1




Photo 2



Photo 3



Photo 4

