

Drivers Side Pedal Board

Mini R50,R52,R53

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.

Check to make sure you have all parts listed prior to installation. If anything is missing contact us immediately.

- (1) Pedal Board face plate (Black or Silver)
- (2) 10/32x1/2" Button head S/S screws - MC92949A265
- (1) Mounting Bracket (Black)
- (2) 10/32 nutserts -C95105A135



1. Remove gas pedal from car by releasing the tension clip on the side of the pedal as shown in photo 1 and sliding the gas pedal to the left as shown in photo 2.
2. Slide the pedal board bracket under the dead pedal as shown in photo 3. This bracket has a special cut out in the end that will lock in place behind the factory dead pedal.
3. Attach the other end of the bracket behind the gas pedal mount using the factory bolt. See photo 4.
4. Re-install the gas pedal.
5. Install the pedal board using the supplied (2) button head screws as shown in photo 5.
6. Enjoy your new Rennline product.