

SECTION 5000- FIXTURE ASSEMBLY

K41 H-RACK END PANEL ASSEMBLY

Start with:

- Assembled K41 H- Rack
- 2x6 Chrome Slatgrid
- Grid Hanger
- Tek Screw
- Nut-Driver Bit
- End Cap Spacer Bracket

1. Check the rack with a level, and adjust the leveling feet if needed.
2. Measure down 1" from the top of the hang bars teardrop end. Begin with a grid hanger & a Tek screw.
3. Fasten a grid hanger to each teardrop end using the provided nut driver bit in a power drill or power screwdriver. Steady pressure is needed to drive the screw through metal.
4. Hang the 2x6 chrome slatgrid by the fourth square from the top.
5. Place an endcap spacer bracket on the back of the slatgrid panel up 2 or 3 squares in line with the racks leg. Attach the spacers to the legs of the rack.

SECTION 5000- FIXTURE ASSEMBLY

K41 H-RACK END PANEL ASSEMBLY (C)

