

# SECTION 2000-DETAIL DRAWINGS

---

## K41 H-RACK ASSEMBLY

Start with:

### **K41 BOX:**

- 2 rectangular frames (with round leveling feet)
  - 1 straight stretcher bar
  - 2 angled bars (labeled Diagonal brace on the diagram)
1. Empty K41 box onto the floor. Assemble the Lower Cross Bar by depressing the push buttons of the components.
  2. Assemble the two Side Frames with the Lower Cross Bar.
  3. Screw in the Levelers to the Side Frames
  4. Using the 1.5" x 3/8" screw, washer and lock washer attach the Diagonal Brace on one side. Repeat this step for the other side. Tighten the lock washers until flat.
  5. Assemble the hang bar by depressing the push buttons on the male half and install it into the female half.
  6. Slide the hang bar uprights in place. Secure with 1/2" x 5/16" screw, washer and lock washer. Repeat this step for the 2<sup>nd</sup> Hang bar
  7. Depress the push buttons and install the hang bars into the unit.

# SECTION 5000- FIXTURE ASSEMBLY

## K41 H-RACK ASSEMBLY

