

SECTION 1000-GENERAL SPECIFICATIONS

WINDOW TREATMENT

NOTE: READ THROUGH ALL INSTRUCTIONS COMPLETELY BEFORE ATTEMPTING TO APPLY THE VINYL GRAPHICS.

ALL VINYL IS TO BE APPLIED TO THE INTERIOR OF THE STORE WINDOWS.

SURFACE PREPARATION FOR WINDOW TREATMENT

1. All surfaces should be considered dirty and cleaned prior to the application of all vinyl.
2. Mark the outside or inside (depending on location specifications) of the window with a level line at the heights specified. (i.e. chalk line)

APPLICATION INSTRUCTIONS FOR WINDOW TREATMENT

1. Use 1" to 2" strips of masking tape to position in proper registry.
2. Apply horizontal tape hinge to the top of the marking.
3. In a spray bottle, mix together two drops of liquid dish detergent with approximately two cups of water.
4. Liberally spray application surface of the glass.
5. Remove the liner entirely and allow carrier paper with logo or text to drape flat against the glass.
6. Liberally spray the backside of the vinyl with the soap mixture.
7. Squeegee entire marking to expel excess moisture and air pockets.
Check on the front side of the application to see if any bubbles remain.
8. Let this dry overnight. Do not re-wet the application before removing the pre-mask.
In the morning, pull the pre-mask back on itself at 180 degrees.

**SMALL AIR BUBBLES WILL ABSORB AND THERE IS NO NEED TO BE CONCERNED ABOUT THEM.
IF LARGE BUBBLES APPEAR, THEY SHOULD BE PRICKED WITH A PIN AND HAVE THE AIR PRESSED**