



A. The top 16 3/4" section is designed to be cut to fit under the counter top. The bottom 13 1/4" needs to remain as is.

B. Aluminum inserts spaced 6" o.c.

C. Optional 4" vinyl cove base to installed to cover uneven floor surfaces.

- "Slate Gray" is the color of the new refacing slatwall.
- The 4' x 8' sheets are designed to be cut both vertically and horizontally with the aluminum inserts in the grooves. When cutting, it is suggested that the sheets be cut from the backside. It is also suggested that masking tape be used over the cut line to reduce splintering. A Carbide tipped blade is recommended.
- The cut slatwall is to be screwed to the existing cabinets through the aluminum insert using a self-piercing screw. Appropriate length screws to be determined by the contractor. In situations where cabinets have already been refaced the current surface may need to be removed to accomodate the new surface. That will need to be determined by the contractor.