

# SECTION 1000 – GENERAL SPECIFICATIONS

## Window Treatment Application

### 1A) LOGO



### 1B) RRR



### Application

- Measure ALL windows pane widths, including door(s). Write down this measurement for later use.
- Decal is applied to EVERY OTHER WINDOW PANE, ALTERNATING DECALS
- Measure width of window statement
  1. Subtract from window width
  2. Divide by 2 to get starting point (in inches from the window edge) to place window decals.
- Bottom of window decal is to be no lower than 2.5' and no higher than 3.5' above ground, depending upon window shape and size
- Place window decal in window first.
  - A. On the OUTSIDE of the window, use a Sharpie to place small dots on your "square line" to show level and boundaries for placement.
  - B. Thoroughly clean the window/placement area
  - C. Using a spray bottle with warm water/soap mixture, heavily saturate the window area.
  - D. Apply the decal using your "level and boundaries" dots.
  - E. DO NOT REMOVE PAPER BACKING YET!
  - F. Use plastic card/squee-gee to remove air bubbles. Check by looking at the statement from outside
  - G. Allow decal to thoroughly dry before removing paper backing
  - H. Once dry, use a small pin to prick the holes in any remaining air bubbles. Press the bubbled area against the window and lightly rub with a plastic card to adhere to window.
- Remove the guide marks on the outside of the window using cleaner and scraper.