



© Copyright 2019  
Earthlite®

All rights reserved. This document or any portion thereof may not be reproduced in any way, including photocopying or translation to another language without the prior written permission from Earthlite.

Earthlite® is a registered trademark of Earthlite, LLC.

#### Legal Notice

The information provided in this document is intended for informational purposes only and is subject to change without notice. The information provided in this document should not be construed as a commitment by Earthlite®.

Earthlite® assumes no responsibility for the accuracy or suitability of the information contained in this document. This document may contain technical inaccuracies or errors. Earthlite® makes no expressed or implied warranties of any kind concerning the information contained in this document, including, but not limited to, the implied warranties of merchantability and fitness for purpose.

Earthlite® shall not be liable for incidental or consequential damages in connection with or arising out of the product, performance, or use of this document and the information and material it describes.

## Important Note Regarding Assembly/Installation

There are 2 different methods that can be used to assemble and install the Universal Hanging Armrest. Review both of the methods in this manual before beginning assembly/install.

**Installation A:** Pages 2-3

**Installation B:** Pages 4-5

If you have further questions, please contact us at (800) 872-0560 for US customers, or (760) 599-1112 for international customers. We can also be reached via e-mail at [info@earthlite.com](mailto:info@earthlite.com).

## Included Parts

- Base with 3 straps x 1
- Cushion x 2
- Loop female clips x 3 (NOTE: 2 female clips and no screws are used if installation A is chosen, and 3 clips and 3 screws are used if installation B is chosen)



## Tools Needed

**Installation A:** no tools necessary

**Installation B:** Philips head screw driver and hole starter (leather awl, ice pick) required

## Installation A Instructions



**Step 1:** Insert headrest into headrest outlet and loop female clips on headrest dowels.



**Step 2:** Loosen the adjustment knob under the armrest platform.



**Step 3:** Clip male connector to female loop on headrest dowel and wrap the strap around the outside leg of table. Repeat on other side.



**Step 4:** Wrap center strap on armrest platform around the bar of the headrest.

**NOTE:** For headrests that don't have a center bar, wrap the strap around the platform base, under the headrest cushion.




**Step 5:** Align armrest platform with inside legs of table, so it rests firmly against table legs.



**Step 6:** Adjust the height of the armrest by tightening the straps around the outside legs.



## Installation B Instructions



**Step 1:** Place female clips along the inside edge of each leg block and center of the table, as shown to the left.

**Step 2:** Using the hole starter, make a pilot hole in the center of the grommet, and install screws.



**Step 3:** Loosen the adjustment knob under the armrest platform.



**Step 4:** Clip male connector to female loop into couplers and rest platform against table legs. Adjust depth of platform by pulling short end of platform straps and checking length.



**Step 5:** Align armrest platform with inside legs of table, so it rests firmly against table legs.



**Step 6:** Adjust the height of the armrest by tightening three straps at the front.



# EarthLite®

WORLD'S #1 BRAND IN MASSAGE™

## Contact Us

Earthlite  
990 Joshua Way  
Vista, CA. 92081  
(800) 872-0560  
(760) 599-1112 Int'l  
(760) 477-6071 fax  
info@earthlite.com

Hours of operation:

Monday - Friday  
8:00 a.m. to 5 p.m. PST

Saturday - Sunday  
Closed

Visit us online at: [earthlite.com](http://earthlite.com)



Join us on  
Facebook



Follow us on  
Twitter



Connect with us  
on LinkedIn



**self-certified**

Made in USA  
of U.S. and  
imported parts