



American Weigh Scales, Inc.

AMW-505

5kg x 1g 11lb x 0.1oz





USER'S MANUAL

American Weigh AMW-505 User's Manual 5kg x 1g

Thank you for purchasing the AMW-505 Digital Scale. With normal care and proper treatment, it will provide you with years of reliable service. Please read all operating instructions carefully before using the scale.

- Avoid any exposure to extreme heat or cold. Your scale will work better when operating in normal room temperature. Allways allow the scale to acclimate to normal room temperature for at least an hour before use.
- Give the scale sufficient warm up time before use. Usually 30 to 60 seconds to give the internal components time to stablize.
- Keep your scale in a clean environment. Dust, dirt, moisture, vibration, air currents, or a close proximity to other electronic equipment can cause an adverse effect on the reliability and accuracy of your scale.
- Handle with care. Gently apply all items to be weighed onto the weighing surface. Although this scale is designed to be quite durable, avoid rough treatment as this may permanently damage the internal sensor.
- Do not shake, drop, or otherwise shock the scale. This is a precision instrument and must be handled with extreme care.
- Only operate the scale on a stable, vibration free surface.
- Always store in a dry place to avoid moisture accumulation on internal components.
- Clean the glass surface using a damp cloth. Do not use corrosive chemicals or submerge in water.

I. Setting Weighing Mode

To switch weighing modes, when the scale is powering up, tap down on the front of the scale before it goes to zero, and when all the LCD segments are showing. You will notice that the weighing modes will change each time you tap on the scale

II. Operation

- 1. Place the scale on a level surface and press down on the front panel near the "ON/OFF" lettering to turn the scale on.
- 2. Wait 2 seconds for the display to show zero, then gently apply all item(s) to be weighed onto the weighing platform.
- 3. The scale will automatically turn off after 2 minutes of no use, however you may press and hold down on the front of the scale for 2 seconds to turn it off manually.

III. Tare Weighing.

- 1. Turn on scale as described above.
- 2. Place the container or tare item onto the platform.
- 3. Tap down once on the front of the scale and wait until [0] is displayed.
- 4. Add the "net-weight-item".

Note: When all weight is removed from the scale, the tared value of a container will be displayed as a negative value. Press the tare button again to return scale to zero.

IV. Batteries

This scale comes with two long-life Lithium CR2032 batteries. Replace batteries if scale is working improperly. To install:

- Remove battery cover.
- 2. Insert batteries positive side (+) up and press into place.
- 3. Replace battery cover.

Note: Batteries must not be disposed of as household waste. Contact your local authority for info on battery disposal.

V. Troubleshooting

The primary reason for innaccuracy or malfunction are low batteries, overload or operating on an unstable surface. Please keep this in mind and maintain and operate your scale properly. This scale is a precision instrument and must be handled with care.

Error Code Descriptions:

-

Error: Nothing on screen, **Solution:** Replace Batteries

Error: [EEEE]

Solution: Load is in excess of 5000g, remove the extra load.

VI. Specifications

Capacity: 5kg; 11lb Graduation: 1g; 0.1oz

Units: kilograms (kg) / grams (g) or pounds (lb) /

ounces (oz)

Calibration: Auto Calibration
Tare Range: Tare full capacity
Auto Off: 120 seconds

Display: 5 digits