## How to Use:

- 1. Zero the scale by ensuring the main slide (2) is at zero, then move zero adjustment slide (3)
- ) left or right until beams are level with base.
- 2. Place item(s) to be weighed in cup (1) and gently move main slide (2) until beams are level with base again.
- If you need to increase capacity (default is
  place weights in the positions shown.

Capacity	4	(5)	6
2 grams	•		
3 grams		•	
4 grams			•
5 grams	•		•
6 grams		•	•
7 grams	•	•	• )