


CAREFULLY READ INSTRUCTIONS PRIOR TO THE FIRST USE OF THE HUB CENTRIC GROUND TENT

SET-UP & CARE INSTRUCTIONS


WHAT YOU NEED TO GET STARTED

COMPONENTS


- 1x Push Out Tent
- 1x Rainfly
- 2x Rainfly Poles
- 1x External Tarp




Stand the collapsed tent upward




Pull the center panel strap handles in order to pop the tent outward






Once all side wall panels are complete, open one of the tent entry ways




SET-UP & CARE INSTRUCTIONS


Push the center skylight tab upward




Attach the pull handle for future reference, when closing the tent




To set up the rainfly poles, insert the pole into the corner sleeve






SET-UP & CARE INSTRUCTIONS


Slip the poles toward the middle and a create a knot for both poles to enter and keep stable



Attach the next small velcro patches to the pole




Insert the pole into the opposite corner




Repeat for the other cross-pole

SET-UP & CARE INSTRUCTIONS

Your rainfly should create a square that you will then position on top of your Hub Centric Tent




Attach all hooks to all 4 sides of the tent




SET-UP & CARE INSTRUCTIONS


When closing the tent, unhook all rainfly hooks from their anchor points. Also make sure you have all guide lines and stakes removed before proceeding



Remove rainfly from tent




Remove the pole from the rainfly sleeves




SET-UP & CARE INSTRUCTIONS

Remove all velcro patches from all poles


Untie the center cross tie





Use the Ceiling Pull Strap to pull down the ceiling of the tent.

8



SET-UP & CARE INSTRUCTIONS


Push all center tabs inward on all 4 sides

8


Put tent in collapsed position upward



Lay tent down and position on top of Storage Strap




Buckle Strap



SET-UP & CARE INSTRUCTIONS

TIPS FOR A LONGER LASTING TENT

 Open the floor slit and be able to sweep out any elements that may get in your tent



- Use cold water and a sponge to wash any stains or dirt from your tent as to preserve the fabric
- Use the floor tarp to keep the bottom of your tent protected from any water or rocks that may scratch your tent

⚠ WARNINGS

- Weather Conditions Do not set up your tent in high winds, severe storms, or areas prone to flash flooding. Always secure with stakes and guy lines.
- Fire Safety Never use open flames, heaters, stoves, or candles inside or near the tent. Keep campfires at a safe distance.
- Ventilation Always maintain proper airflow to reduce condensation and avoid buildup of harmful gases.
- Site Selection Do not pitch your tent under dead tree limbs, on unstable ground, or in low-lying areas that may collect water.
- Anchoring Ensure tent is properly staked and guy lines are tensioned before leaving unattended.
- Animals & Wildlife Do not store food inside the tent. Use proper food storage to avoid attracting wildlife.
- UV & Heat Exposure Extended sun exposure may degrade materials.
 Whenever possible, set up in shaded areas or use a tarp/awning for protection.
- Children & Pets Supervise children and pets around the tent to prevent accidental damage or injury.
- Storage & Transport Make sure the tent is completely dry before storage to prevent mold, mildew, and fabric damage.



DO YOU NEED OUR HELP?







SALES@OVERLANDVEHICLESYSTEMS.COM

