

For using DC-S160.

Before operating your DC-S160, please read this manual thoroughly and remain it for future reference.


NIPPON VIDEO SYSTEM accepts no liability whatever for incidental damages arising out of the use or inability to use the product, including, but not limited to, damage to the camera, etc., corruption or loss of data, lost business revenue or suspension of business operations.

NIPPON VIDEO SYSTEM accepts no liability whatever for damages arising from improper use not conforming to the instructions in the instruction manuals.

■ Features

- Connecting the DC-S160 to the DC power output 4P connector of the camera adaptor or the shoulder adaptor ST-7, outputs the DC power to the SONY camcorder, PMW-160, etc.

■ Dimensions



■ Specifications

Specifications	
Connector	1 × Mini 4-pin connector, male 1 × DC connector. EIAJ No.4, for SONY
Cable Length	0.5 m

NOTE Features, design and specifications are subject to change without notice.