SKAGEN

urbnliving



SCAN TO SHOP

Visit our website at **urbnliving.co.uk** and claim 15% OFF your next order using code **HOME15**

Dear Customer

Thank you for your order. We hope that you have received your furniture in the pristine condition that we sent it out in.

In the unfortunate event that your order was mishandled during transit, please contact us to let us know the extent of the damages so we can resolve for you as soon as possible.

If replacement parts are required, please email us with images and the part number referenced in this manual and we will have a replacement sent out right away.

We can be reached by the following email: cs@egtrading.co.uk.

Please include the full name and postcode used to place the order in your email so we can locate your order in our systems.

Alternatively, we can be reached by phone (Mon – Fri) on: 0161 401 6140.

The Customer Satisfaction Team

ASSEMBLY INSTRUCTIONS

SKAGEN 2-DOOR SLIDING WARDROBE-CARCASS

Lower wardrobe body.
Sliding doors: see page 10.
Five adjustable feet are required for the base.



P1			5 PCS
P2			5 PCS
P3		M4X35mm	2 PCS
P4		M8x30mm	9 PCS
P5		M3.5x12mm	38 PCS
P6			1 PC
P7		M5x40mm	10 PCS
P8			26 PCS
P9			24 PCS
P11			4 PCS
P12			4 PCS
P13			2 PCS
P15			1 PC
P16			2 PCS
P17			4 PCS
P18			2 PCS
P20		M4X25mm	4 PCS
P21		M5X25mm	6 PCS


1
P5
P13
P5x2
x4
P13
9
P5x2
P13
10


2
x6
9
10
34
P4x4
14
P7x6
x4
3
x4
35
P7x4
9
10

4



5



6



7



8



9



10



11



The adjustable feet need to be purchased separately.

Fit the feet according to the instructions supplied with the feet pack.

ASSEMBLY INSTRUCTIONS

SKAGEN 2-DOOR SLIDING WARDROBE-2 DOORS

Lower wardrobe: two sliding doors (part 19).




1
P11
P11
P11
P5x16
P5
19
P12
P12
x2
P12
P5
2
19


3
19
4
19

ASSEMBLY INSTRUCTIONS

SKAGEN 2-DOOR SLIDING CABINET

Upper cabinet.
Do not fit legs or feet to this unit.



P1			5 PCS
P2			5 PCS
P3		M4X35mm	2 PCS
P4		M8x30mm	9 PCS
P5		M3.5x12mm	34 PCS
P6			1 PC
P7		M5x40mm	6 PCS
P8			18 PCS
P9			13 PCS
P11			4 PCS
P12			4 PCS
P15			1 PC
P16			2 PCS
P17			4 PCS
P18			2 PCS
P20		M4X25mm	4 PCS
P21		M5X25mm	4 PCS


1
P11
P5
P11
P11
P5x16
7
P12
P12
x2
P12
P5
2
x6
36
3
2
P4x4
6
P7x6
x4


3
P1
P1
P1
P1
P1
1
x5
4
1
P4x5
x5
3
P2x5
36
2
x5

5



6



7



8



9



10



Join the upper cabinet to the lower wardrobe



2-Door Sliding Wardrobe + 2-Door Cabinet

Use the four P20 fixings shown. Keep the upper cabinet supported while positioning and securing it.

11



Upper cabinet shown alone for clarity. It sits on the wardrobe; no legs or feet are fitted to the upper cabinet.

Care & support

Care and maintenance

Check all fittings periodically and re-tighten as necessary.

Clean with a damp cloth and wipe dry.

Do not leave liquid on the furniture. It may warp the wood or cause the finish to peel or delaminate.

Do not place hot items, such as hot drinks, directly on the surface.

Do not drag or pull the furniture.

Missing or damaged parts?

Contact us with photographs and the part number shown in this guide. Include the full name and postcode used for your order so we can locate it.

cs@egtrading.co.uk

0161 401 6140

Monday to Friday

UrbnLiving Customer Satisfaction Team

urbnliving.co.uk