






ITEM NAME / NOM D'ITEM: AURAY BAR TABLE

ITEM # / NO.ITEM: 109828/109829/109830

PARTS LIST / LISTE DES PIÈCES


(1)	(2)	(3)	(4)	(5)
				
x1	x1	x1	x1	x1

(7)


A. M6 x 16MM		x4	G. Ø10MM		x3
B. M8 x 40MM		x3	H. Ø12MM		x1
C. M12 x86MM		x1	I. Ø8MM		x4
D. Ø10MM		x3	J. 4MM		x1
E. Ø12MM		x1	K. 5MM		x1
F. Ø8MM		x4	L. 10MM		x1

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE


I



II



III



Please avoid
overtightening screw
C, as it may cause
the base to crack.

IV

Flip over

