


ITEM NAME / NOM D'ITEM: ROXAS DINING CHAIR

ITEM # / NO.ITEM: 109979

NO ASSEMBLY REQUIRED



Please use the attached adjustable footglides to level the chair on uneven surface.

For missing parts or damaged parts, please call /
Pour pièce manquante ou endommagée, veuillez appeler: USA, Canada and Mexico : (866)798-6663

AI-V1-240615