





**ITEM NAME / NOM D'ITEM : DISQUE DINING TABLE**

**ITEM # / NO. ITEM : 110507**

**PARTS LIST / LISTE DES PIÈCES**

(1)	(2)	(3)	(4)
			
X1	X1	X1	X1


(6)

A.  M6 x 40mm	X12	C.  M6	X18
B.  M6 x 30mm	X6	D.  M4 x 110mm	X1
E.  M6 x 12mm	X18		


**ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE**

**Do not FULLY TIGHTEN the screws or nuts for any step until all are in place.**

I Remove (3) from (1) by unscrewing the hardware as shown in the diagram below.




II Make sure all hardware is securely tightened after all are in place.




III

Make sure all hardware is securely tightened after all are in place




IV

Make sure all hardware is securely tightened after all are in place.



V



For missing parts or damaged parts, please call /  
Pour pièce manquante ou endommagée, veuillez appeler :

USA, Canada and Mexico : (866)798-6663

AI-V2-C008-250414