


ITEM NAME / NOM D'ITEM: NUBY DINING CHAIR

ITEM# / NO. ITEM: 110786

NO ASSEMBLY REQUIRED



Please use the attached adjustable footglides to level the chair on an uneven surface.