


# data sheet

## **ARGCO**



### **SOLID CAST WALL PLATES**


#### **GALVANIZED CAST IRON WALL PLATES with SET SCREW**



Heavy duty pre-galvanized cast steel with set screw  
Designed for light stabilization of pipe penetrating wall or floor structures.  
Features one piece rigid construction.  
Each wall plate has been pre-galvanized to resist corrosion and is provided with a set screw to keep the wall plate in place.

Material:  
Malleable Iron Pre-Galvanized ASTM A48 Grade 32510

Available in sizes 1" IPS through 6" IPS.



#### **INSTALLATION:**

Each wall pipe should be installed on the corresponding pipe size to maintain proper fit and performance. The wall plates' rigid construction requires that it be installed as the pipe to be fitted is put in place.  
As the pipe is being installed through the surface to which the plate will provide stability, install the wall plate over the end of the pipe and move to it's desired location.  
Once the length of pipe has been properly installed and the pipe hangers have been adjusted to their final elevation, move the wall plate to it's final desired location. Tighten the set screw while maintaining the wall plate in its' desired final location. If the wall plate is being used to prevent the movement of pipe through the "wall" or floor penetration.  
It is necessary to use one wall plate on each side of the wall or floor to secure the pipe from additional movement.

This product is not suitable or approved as earth quake bracing.

ITEM #	SIZE	I.D.	O.D.
4519005	1" IPS	2-7/16"	3-3/4"
4519010	1-1/4" IPS	1-11/16"	4"
4519115	1-1/2" IPS	1-15/16"	4-1/4"
4519120	2" IPS	2-7/16"	4-11/16"
4519125	2-1/2" IPS	2-15/16"	5-1/2"
4519130	3" IPS	3-5/8"	6"
4519135	4" IPS	4-9/16"	7-1/16"
4519140	6" IPS	6-3/4"	9-3/4"

The information contained herein is produced in good faith and is believed to be reliable but is for guidance only. ARGCO and its agents cannot assume liability or responsibility for results obtained in the use of its product by persons whose methods are outside or beyond our control. It is the user's responsibility to determine the suitability of any of the products, methods of use, or preparation prior to use, mentioned in our literature. It is the user's responsibility to observe and adapt such precautions as may be advisable for the protection of personnel and property in the handling and use of any of our products.

**FOR MORE INFORMATION CALL ARGCO AT 1-800-854-1015  
OR LOG ONTO WWW.ARGCO.COM**