

TeleGlide Riser Order Guide

Schier Model	GB-35 & 50		Schier Model	GB-75 & 125		GB-250	
Riser Item #	SR24	LR24	Riser Item #	SR24	LR24	SR24	LR24
>3"-26"	1	0	>6"-29"	1	0	2	0
>26"-37"	0	1	>29"-40"	0	1	0	2
>37"-49"	2	0	>40"-52"	2	0	4	0
>49"-61"	1	1	>52"-64"	1	1	2	2
>61"-73"	0	2	>64"-76"	0	2	4	4