CHAINWAY®

C66

Handheld Computer

Accessories

Standard

Adapter

PWR-C66-5V2A-CN

PWR-C66-5V2A-EU

PWR-C66-5V2A-UK

PWR-C66-5V2A-US

Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-BK-TypeC cable

QC Adapter

PWR-18W-CN

PWR-18W-EU

PWR-18W-UK

PWR-18W-US

Quick Charge adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V3A/12V1.5A/9V2A, use with DC-BK-TypeC cable

Comment: standard adaptor and QC adaptor are alternative.

USB Cable

DC-BK-TypeC

1.0 meter Type-C cable

Battery

BTRY-C66-43MA

4300mAh Li-ion battery, 3.8V ouput

Optional

Rugged Rubber Boot

RB-C66-RR/RB-C66-RRP

Rugged Rubber Boot only, omni-directional protected.

RB-C66-RR does not support charging cradle.

RB-C66-RRP is pre installed with Type C & Pogo Pin I/O connector ,then it supports CRD-C66-RBC/CRD-C66-RBCE charging cradle.

RB-C66-RRH/RB-C66-RRHP

Rugged Rubber Boot with hand strap, omni-directional protected.

RB-C66-RRH does not support charging cradle.

RB-C66-RRHP is pre installed with Type C & Pogo Pin I/O connector ,then it supports CRD-C66-RBC/CRD-C66-RBCE charging cradle.

RB-C66-RRC/RB-C66-RRCP

Rugged Rubber Boot with belt clip, omni-directional protected.

RB-C66-RRC does not support charging cradle.

RB-C66-RRCP is pre installed with Type C & Pogo Pin I/O connector ,then it supports CRD-C66-RBC/CRD-C66-RBCE charging cradle.

RB-C66-P

Type C & Pogo Pin I/O Connector, to be mounted with the rugged rubber boot, enable it to support charging cradle(CRD-C66-RBC/RBCE).The wired network is available when the rugged rubber boot is placed on the cradle(CRD-C66-RBCE).

RB-C66EXT-RR / RB-C66EXT-RRP

Rugged Rubber Boot only,omni-directional protected.Support for volume measurement/built-in UHF/fingerprint device.

RB-C66EXT-RR does not support charging cradle.

RB-C66EXT-RRP is pre installed with Type C & Pogo Pin I/O connector, then it supports CRD-C66EXT-RBC/CRD-C66EXT-RBCE charging cradle.

Charging Cradles & Adapters

CRD-C66-MBC

Charging Cradle for main battery, up to 4 slots, use with DCP-WR-12V2A-XX adapter.

CRD-C66-PBC

Charging Cradle for pistol battery, up to 2 slots, use with DCP-WR-12V2A-XX adapter.

CRD-C66-DP

C66 charging cradle,only for device with pistol grip or device with UHF,use with DCPWR-12V2A-XX adapter.

DCPWR-12V2A-XX

Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 12V2A, DC

CRD-C66-RBC/CRD-C66-RBCE

Charging Cradle for device, use with DCPWR-12V2A-XX adapter.

CRD-C66-RBCE is an advanced CRD-C66-RBC, w/sync, w/ethernet, w/DC.

The cradle cup has an insert that must be removed prior to inserting the C66 with Rugged Boot.

CRD-C66-RBC / CRD-C66EXT-RBCE

Charging Cradle for volume measurement/built-in UHF/fingerprint device, include the cradle cup(CRD-C66EXT-INS),support volume measurement, built-in UHF and fingerprint device, use with DCPWR-12V2A-XX adapter.

The cradle cup has an insert that must be removed prior to inserting the volume measurement, built-in UHF and fingerprint device with Rugged Boot.

CRD-MCB

The base of 4-slots charging cradle set for 4 pieces of cradle，use with DCPWR-12V5A-XX adapter.

For load balance, recommendation：

1. 4 x cradle for device
2. 3 x cradle for device + 1 x cradle for main battery
3. 2 x cradle for device + 1 x cradle for main battery + 1 x cradle for pistol battery

Vehicle Cradle

CRD-C66-VC

Vehicle Charger Cradle, with type-C，use with DC-BK-TypeC cable. Car holder and car adapter need to be purchased separately

Rubber Bumper

RB-C66-PR

Protective rubber bumper, upper and lower

4 pcs M1.6 screws are necessary.

Hand Strap

RB-C66-HS

Hand strap with buckle

2 pcs M1.6 screws are necessary.

Screen Protector

SP-C66

Tempered glass screen protector

Pistol Grip

RB-C66-PS

Snap-On Trigger Handle and Rugged Boot Kit, use with optional pistol battery

4 pcs M1.6 screws are necessary.

BTY-C66-PB

Pistol battery, 5,200 mAh

Address: 9F, Building2, Phase 2, Gaoxinqi Industrial Park, Liuxian 1st Rd., Bao'an District, Shenzhen, Guangdong 518102, China

Tel: 0086-755-23223316 Email: sales@chainway.cn

Fax: 0086-755-23223310 Web: http://www.chainway.net