

R2

Bluetooth RFID Reader

Accessories



STD. Spec.

Adapter

PWR-R2-5V2A-CN

PWR-R2-5V2A-EU

PWR-R2-5V2A-UK

PWR-R2-5V2A-US

Adapter(CN/EU/UK/US), , I/P: 100-240V, O/P: 5V2A, use with DC-R2/R6-USB cable

USB Cable

DC-BK-MicroUSB

1.0 meter Type-C cable

Battery

BTRY-R2-52MA

5200mAh Li-ion battery

Optional

Charging Cradles & Adapters

CRD-R2-MBC

Charging Cradle for battery, up to 2 slots, use with DCPWR-12V2A-XX adapter.

DCPWR-12V2A-XX

