



OAK BOK TABLE TOP ASSEMBLY INSTRUCTION FOR TABLE TOP INSTALLATION



HARDWARE ENCLOSED



TOOL REQUIRED



IN YOUR PACKAGE :

ASSEMBLY INSTRUCTION


PARTS TO BE INSTALLED

1. TABLE TOP

- 51515 / 51520 OAK BOK TABLE TOP 140
- 51516 / 51521 OAK BOK TABLE TOP 170
- 51517 / 51522 OAK BOK TABLE TOP 200

2. LEG BASE

- 59216 / 59219 METAL ADJUSTABLE TABLE BASE - EU
- 59217 / 59220 METAL ADJUSTABLE TABLE BASE - UK
- 59218 / 59221 METAL ADJUSTABLE TABLE BASE - US



SYMBOLS




DIRECTION



NUMBER OF
PERSON NEEDED




USE HAND



USE DRILLING MACHINE
TO TIGHTEN

NOTICE



A. EXTEND LEG BASE







TABLE TOP SIZE (CM)	X (CM) (distance between pre-drilled holes)
140 x 72	112,4
170 x 80	131,4
200 x 88	155,4



B. INSTALLING LEG BASE TO TABLE TOP




- TABLE TOP WITH PRE-DRILLED HOLES

- USE SOMETHING SOFT AS BASE TO PROTECT TABLE TOP FROM SCRATCHES


OAK BOK TABLE TOP ASSEMBLY INSTRUCTION FOR TABLE TOP INSTALLATION



C. INSTALLING CONTROLLER BOX



D. HOW TO RESET THE LEG BASE



LOWER THE LEG BASE TO ITS LOWEST POSITION BY PRESSING THE DOWN ARROW ON THE HAND CONTROL. RELEASE THE BUTTON. PRESS THE BUTTON AGAIN AND KEEP IT PRESSED FOR 10 SECONDS. THE RESET IS NOW CARRIED OUT AND THE LEG BASE IS READY TO USE.