



BOK ROUND DINING TABLE - OUTDOOR ASSEMBLY INSTRUCTIONS FOR DINING TABLE INSTALLATION

HARDWARE & TOOLS ENCLOSED

 <p>SPAX SCREW (8pcs) M6 x 100</p>	 <p>WASHER (8pcs) M8x23</p>	 <p>SPRING WASHER (8pcs) M6</p>	 <p>TORX ALLEN SCREW (Included in package)</p>
--	---	---	--



IN YOUR PACKAGE :
ASSEMBLY INSTRUCTIONS
HARDWARE (AS LISTED ABOVE)

PARTS TO BE INSTALLED


1. TABLE TOP 1pc
2. LEGS 4pcs

 **LEGS ARE INTERCHANGEABLE**

SYMBOLS



DIRECTION



NUMBER OF PERSONS NEEDED





USE HAND





USE TORX ALLEN SCREW TO TIGHTEN

NOTICE


BOK ROUND DINING TABLE - OUTDOOR ASSEMBLY INSTRUCTIONS FOR DINING TABLE INSTALLATION

A. ATTACHING LEGS TO TABLE TOP





- NOT TOO TIGHT
- TO BE RE-TIGHTENED AFTER 15 DAYS
- REPEAT STEP 1 TO STEP 3 FOR OTHER LEGS

B. ADJUST LEVELER



NOTICE



IMPORTANT NOTICE :

TO PREVENT WARPING, BEFORE USING A TABLE,
ALWAYS ADAPT THE ADJUSTABLE GLIDES OF THE EACH LEGS TO THE GROUND SURFACE.
FOR STABILITY, EACH LEGS NEED TO BE SLIGHTLY SHORTER.