


Model Cocoon · Design by Jens Juul Eilersen

Arm height (frame): 28 ¾" · Arm width: 2 ¾" · Total depth (frame): 41 ¾" · Seat depth: 22 ¾" · Seat height: 14 ¼" · Total height (frame): 28 ¾" Also available with low arm and back (height 24 ¾")







Model Cocoon · Design by Jens Juul Eilersen

Arm height (frame): 28 %" · Arm width: 2 %" · Total depth (frame): 41 %" · Seat depth: 22 %" · Seat height: 14 %" · Total height (frame): 28 %" Also available with low arm and back (height 24 %")

Easy Chair 45" x 41 ¾"	Closing section 51 1/4" x 41 3/4"
Corner section 41 ¾" x 41 ¾"	Closing section 55" x 41 3/4"
Centre section 39 ½" x 41 ¾"	Chaiselong 47 1/4" x 65 1/4"
Closing section 43 ½" x 41 ¾"	Footstool 39 ¼" x 23 ½"
Closing section 47 ¹ / ₄ " x 41 ³ / ₄ "	Footstool 47 ¼" x 23 ½"





Model Cocoon · Design by Jens Juul Eilersen

Cocoon is inspired by the pupa stage of the silkworm. You can go into a cocoon of cushions with 100% individual and flexible levels of comfort. Individualism and diversity have been demanded for many years. Some people want to float. Others want to sit. A sofa is often either—or, but not Cocoon. Here is a cornucopia of both worlds. In your safe and solid cocoon frame you have a gigantic toy box with triangular cushions, lumbar bolsters, main cushions, armrests, neck bolsters — in fact, cushions of all sizes and shapes. This method allows you to determine the degree of comfort yourself, and at the same time be able to have great fun building and being in the sofa.

Cocoon supports you all the way round. Primarily with its high back, but also the seats, which feature Eilersen's renowned down top, giving both firmness and softness at the same time. Here's a little recommendation for you when you design your Cocoon: buy cushions and elements in different fabric design when you choose your sofa's style. That will give you a truly unique cocoon.

